

## USER MANUAL

### USB RECHARGEABLE MOSQUITO KILLER WITH LED LIGHT



## IMPORTANT SAFETY INSTRUCTIONS

### WARNING

1. KEEP OUT OF REACH OF CHILDREN.
2. DO NOT USE THE PRODUCT NEAR ANY HEAT SOURCE, STEAM OR CORROSIVE GASES.
3. KEEP AWAY FROM FLAMMABLES SUCH AS PAPER, CLOTHING OR ANY MATERIAL THAT CAN CATCH ALIGHT.
4. RISK OF ELECTRIC SHOCK - DO NOT INSERT ANY OBJECT THROUGH THE GRID OR TOUCH THE WIRES WHEN THE PRODUCT IS ON.
5. NEVER WASH OR SOAK THE PRODUCT IN WATER FOR ANY LENGTH OF TIME. THE PRODUCT IS RAIN RESISTANT.
6. FOR CLEANING OF THE WIRE GRID ONLY USE A SUITABLE NON CONDUCTIVE TOOL SUCH AS A BRUSH.

### CUSTOMER INSTRUCTION

1. CHARGE THE PRODUCT VIA THE USB CABLE (INCLUDED).
2. THIS DEVICE USES TOUCH BUTTONS SO ONLY REQUIRE LIGHT CONTACT WITH YOUR FINGER TO OPERATE.
3. GENTLY TOUCH THE "LIGHT BULB" BUTTON FOR USE AS A LANTERN.
4. GENTLY TOUCH THE "MOSQUITO" BUTTON AND THE MOSQUITO KILLER PORTION WILL BE TURNED ON.
5. BOTH THE ABOVE FUNCTIONS CAN BE UTILISED AT THE SAME TIME OR INDEPENDENTLY.
6. THE MOST EFFECTIVE TIME OF DAY TO USE THIS PRODUCT WILL BE AT NIGHT WHEN THE PRODUCT IS AWAY FROM COMPETING LIGHT SOURCES.
7. PLEASE USE ADAPTOR 5V, 1A FOR THE CHARGING OF THE DEVICE.

### CARE INSTRUCTION

1. FREQUENT CLEANING WILL PROLONG THE LIFE OF PRODUCT, ENSURE FIRE PREVENTION AND PROVIDE A MORE EFFICIENT OPERATION.
2. BEFORE CLEANING THE GRID WITH THE BRUSH, ENSURE THE UNIT IS TURNED OFF.
3. WIPE THE PLASTIC PORTION OF THE PRODUCT WITH A DAMP CLOTH.

**SAVE THESE INSTRUCTIONS**

MADE IN CHINA

Size: 180x160mm