


Spy Pen



HOW TO PLAY

1. Remove the pen cap.
2. Write your message on any paper, the message is invisible.
3. Press and hold the light switch, then shine the decoder light on the paper to read the invisible message.
4. Hide the paper with invisible message in a secret location or pass it to a friend to decode.
5. Always put the pen cap back when you have finished writing.


Note: Press the pen tip onto a damp cloth or sponge to moisten it if the cap doesn't cover for a long time and the pen tip dries out.



HOW TO UNLOCK THE SECRET STORAGE

1. Unscrew the upper part of the pen counterclockwise to completely separate it from the bottom.
2. Hide and store the message papers or other small items into the secret storage.
3. Pen set includes a roll of paper which can be replaced by using your own paper.

BATTERY INSTALLATION



WARNING: CHOKING HAZARD—SMALL PARTS. NOT SUITABLE FOR CHILDREN UNDER 3 YRS.

WARNING: BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY (+ AND -). DO NOT MIX DIFFERENT TYPES OF BATTERIES OR NEW AND USED BATTERIES. NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED. RECHARGEABLE BATTERIES ARE ONLY TO BE CHARGED UNDER ADULT SUPERVISION. RECHARGEABLE BATTERIES ARE TO BE REMOVED FROM THE TOY BEFORE BEING CHARGED. THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED. REMOVE BATTERIES FROM THE TOY WHEN NOT IN USE FOR EXTENDED TIME OR WHEN BATTERIES BECOME EXHAUSTED. BATTERY INSTALLATION BY AN ADULT IS REQUIRED. DISPOSE OF BATTERIES RESPONSIBLY. DO NOT DISPOSE OF IN FIRE.

WARNING: FOR SAFETY REASONS, REMOVE ALL TAGS, LABELS AND PLASTIC FASTENERS BEFORE GIVING THIS TOY TO YOUR CHILD.

PRODUCT MAY VARY FROM IMAGE SHOWN. PLEASE KEEP THE PACKAGING FOR FUTURE REFERENCE.

WARNING: DISPOSE OF USED BATTERIES IMMEDIATELY. KEEP NEW AND USED BATTERIES AWAY FROM CHILDREN. IF YOU THINK BATTERIES MIGHT HAVE BEEN SWALLOWED OR PLACED INSIDE ANY PART OF BODY, SEEK IMMEDIATE MEDICAL ATTENTION.



WARNING: BUTTON CELL BATTERIES CAN CAUSE SERIOUS INJURY OR DEATH IF SWALLOWED. DISPOSE OF SAFELY! STORE BATTERIES OUT OF REACH OF CHILDREN! VISIT THEBATTERYCONTROLLED.COM.AU



KEYCODE: 42887911