

尺寸：80x160mm
 材料：80g书写纸
 颜色：双面单色印刷
 工艺：不用折
 备注：青色裁切线不要印刷出来

正面

80mm

背面

160mm

anko
 Portable Charger User Manual
 42899884

Accessory list:
 Micro-USB charging cable X 1

- 1 Power Button
- 2 LED Display
- 3 USB-C Output
- 4 Micro-USB Input
- 5 USB-A Output

Use the USB-A port to charge your mobile

Use the USB-C port to charge your tablet

Charge the battery pack itself by a USB power adapter

Charge the battery pack itself by a PC's USB port

Specification:

Capacity	3.7V ≈ 20000mAh battery capacity, 74Wh
Battery type	Lithium ion polymer battery
Input Port	Micro-USB
Rated Input	5V ≈ 2.1A
Output Port	USB-A; USB-C
Rated Output	USB-A: 5V ≈ 2.1A, USB-C: 5V ≈ 2.1A
Total Output	Total maximum output: 10.5W
Charging Time	Approx. 11 hours

Important Safety Information:

1. Before using the unit please read the manual carefully.
2. To preserve battery lifespan, use and recharge at least once every 3 months
3. For long time storage over 3 months, charge the device between 50 percent to 75 percent charge level.
4. This product shall not be exposed to dripping or splashing. Keep away from any water, liquid or wet areas.
5. Keep away from temperature over 45 C.
6. Make sure the product has plenty of ventilation during charging.
7. Always use a dry cloth to clean this product. Do not use chemicals on this product.
8. When the unit is not in use, make sure it is correctly turned off and stored in a cool dry place.
9. Adult supervision is recommended with children using this product.
10. Ensure children and infants do not play with plastic bags or any packaging materials.
11. Avoid dropping or standing on the product, as harsh impacts could damage the product.
12. Do not insert foreign object into the product.
13. Do not try to repair or disassembly this product.
14. Do not place the product in direct sunlight, heat or the under the windshield.
15. Do not charge the Portable Charger and charge your device simultaneously.
16. This product should be only operated from the type of power source indicated on the marking label.

12 Month Warranty

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or alternatively, via Customer Help at Kmart.com.au for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

Trusda 深圳市创世达实业有限公司

	公差表			
	A	B	C	D
0-5	±0.07	±0.10	±0.15	±0.20
5-20	±0.10	±0.15	±0.20	±0.30
20-50	±0.15	±0.20	±0.30	±0.40
50-	±0.20	±0.30	±0.40	±0.60

产品编号	KM4	零件名称	说明书	零件料号	
产品名称	移动电源	图号	KM4-SMS3384B	版本	B
材料		处理工艺		单位	mm
比例		客户编号		日期	2020-05-12
制图:		审批:		批准:	

标记	修改前	修改后	修改日期
①		修改内容	2020-05-12
②			

1

2

3

4