

anko

User Manual

Bluetooth® Car Handsfree Earpiece USB Charger

42902003



Notice :

Please read user manual carefully before any operations and keep it for your records.

Safety instructions:

Please read all safety instruction warnings carefully before using this product. Improper use of this product may result in damage to this or attached products. To ensure the production works well, please never use this in the following conditions:

1. Moist or underwater conditions.
2. Conditions near heater or high temperature service.
3. Conditions with direct and strong sunshine.
4. Do not use chemical solvent on cleaning this product.
5. This Bluetooth earpiece shall be charged by the supplied car charger only

CAUTION

Danger of explosion if battery is incorrectly replaced. Do not replace the battery by yourself.

Battery cannot be subjected to high or low extreme temperatures, low air pressure at high altitude during use, storage or transportation.

Replacement of a battery with an incorrect type that can result in an explosion or the leakage of flammable liquid or gas.

Disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion.

Leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas.

A battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.

Packing contents:

Car Charger x 1

BT Earpiece x 1

User manual x 1

Features:

1. Wirelessly transmits phone call & audio streaming to the BT earpiece via Bluetooth.
2. Power from the cigarette socket in the car (DC 12V/24V)
3. One USB port output: DC 5V/2.1A
4. **Siri/Google Assistant** activation. Touch the earpiece for 2s to quick activate Siri/Google assistant under Bluetooth connected

Operation Instructions:

Car charger Function

The device has a 5V/2.1A USB output port that can be used to charge your devices via a USB cable (Not included).

Power Off

1. Touch earphone for 3s to shutdown manually.
2. Earphone will turn off automatically after 3mins when disconnected with Bluetooth device.
3. Earphone will turn off automatically during charging in car charger.

Bluetooth function:

Pairing a Bluetooth device for the first time

4. Take out earphone and touch the touching area for 3s for power on, with a voice prompt: "power on" and "pairing".
5. Turn on your external device. Refer to its user manual for instructions on pairing and connecting Bluetooth devices.
6. Using the native controls on your Bluetooth device, select Bluetooth device name
7. 'KM42902003" in your Bluetooth settings menu to pair.
8. When successfully paired and connected, a sound will issue from the unit.
9. After initial pairing, the unit will stay paired unless unpaired manually.

10. If your device asks for a pairing password, use “0000” or “1234” to complete the pairing
11. If you have used Bluetooth connection before, the system will start searching for the device last connected. When the device is found, the system will re-connect automatically.

NOTE: Should your device become unpaired or you are not able to connect it, repeat the above steps.

Operation Guide:

Operation Guide	BT Earphone
1. Power on/off	Press the touch sensor area for 3s to power on / off.
2. Play and stop the music.	Short press the touch sensor area.
3. Change music	Next track, double press on touch sensor area for next song. Previous track, triple press on touching sensor area
4. Hands-free function	Income call, Press the touch sensor to answer or end the phone call Reject call, long press the touch sensor area to reject incoming call
5. Siri/Google Assistant activation.	Press and hold touch sensor for 2s to activate Siri/Google assistant under Bluetooth device connected

Specification:

- Bluetooth version: V5.0
- Bluetooth receiving distance: ≤10 meters (open area)
- Lift time: Talk time: about 2 hours
Music play time: about 2 hours
Standby time: 24 hours
- Charging time: around 40 minutes.

12 Month Warranty

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where

the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or alternatively, via Customer Help at Kmart.com.au for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.