

JUMP SHOES INSTRUCTIONS

Keycode: 42909538

ADULT SUPERVISION REQUIRED

Read and understand this entire manual before allowing your child to use this product. For safety and best performance, be sure to exercise caution and abide by all of the listed specifications and instructions.

Failure to abide by these instructions may result in injury.

PRECAUTIONS

Like any other moving products, Jump Shoes can be a hazardous activity and it is possible to get into dangerous situations. Be sure to read the entire manual before use. Specifically, pay attention to the following points:

1. Always wear proper protective equipment, such as a helmet, wrist guards, elbow pads, knee pads, long sleeve shirt, gloves, and long pants. Always wear a helmet when using your Jump Shoes and keep the chinstrap securely buckled. Make sure you stay visible wearing bright clothing so people can see you. Carefully open each boot and slip them on over your shoes and tighten the straps until snug and comfortable.
2. Always make sure your Jump Shoes are done up properly with the straps tight and secure.
3. Use the Jump Shoes only on flat level ground. Do not use the Jump Shoes on wet and uneven ground with rocks or gravel. In addition, do not use the Jump Shoes at dusk or night or in wet conditions.
4. Do not use the Jump Shoes on slippery or wet ground, as the tread can slip out of control. Avoid streets and surfaces with water, oil, sand, gravel, dirt, leaves and other debris. Wet weather impairs traction and visibility.
5. Learn the basics such as balance and control. Do not use the Jump Shoes on steep slopes as it can damage the product and/or make it difficult to stop bouncing.
6. Avoid sharp bumps, drainage gutters and sudden surface changes. Jump Shoes may suddenly stop.
7. All children and preteens should use the Jump Shoes with **adult supervision** at all times. The supervisor should inspect the Jump Shoes prior to use, making sure all parts are fully assembled and tightened to prevent accidents. **User's maximum weight: 40kg.**
8. Always follow and obey all local traffic laws and regulations. Stay away from motor vehicles and watch out for pedestrians. Never allow yourself to be pulled by vehicles while using the Jump Shoes. Always be aware of your surroundings.
9. Do not make any modifications to this product. Do not use any attachments that are not included in the Jump Shoes.

10. Please note to remove any sharp edges created through use.
11. Injury may occur if the precautions above are not observed.

CHECK BEFORE USE

Make sure you carry out the following inspections before using your Jump Shoes. Make sure the straps are secured tightly for a safe ride. Make sure the tread is not worn out.

USER GUIDE AND MAINTENANCE

1. Before and after each use make sure the Jump Shoes are free from dirt and dust. Wipe with a damp cloth if needed.
2. The tread may wear through with use.
3. Always keep your Jump Shoes clean. Do not use industrial cleaners or solvents, as they may damage the surfaces. Do not use alcohol, alcohol-based or ammonia-based cleaners as they may damage or dissolve some components or soften the material.
4. Make sure all components are assembled and secured sturdily before each use.
5. Self-locking nuts and other self-locking fixings may lose their effectiveness over time. If any of these components are no longer functioning how they should, it is strongly recommended that you discontinue use of this product.

MADE IN CHINA

FOR AU / NZ: IMPORTED FOR KMART
STORES IN AUSTRALIA AND NEW ZEALAND.