

# anko

## User Manual

Bluetooth® Hands Free Kit

42913061

### Notice :

Please read user manual carefully before any operations, and keep it for your records.


### Safety instructions:

1. Do not disassemble this product.
2. This product is not a toy. Use extra caution while children are using this product.
3. Keep the speaker away from direct sunlight, fire and high voltage equipment.
4. Speaker shall not be exposed to excessive heat such as sunshine, fire or the like.
5. Device may become warm while charging.
6. No naked flame sources such as lighted candles should be placed on the apparatus.
7. Attention should be drawn to the environmental aspects of battery disposal.
8. Use of apparatus in moderate climates.

### Packing contents:

1. Bluetooth® Hands Free Kit x 1
2. USB charging cable x 1
3. User manual x 1

### Function Panels:





### Charging:

The speakers are powered via an integrated rechargeable battery. The battery cannot be removed or replaced.

Upon initial use, the battery should be charged fully to ensure optimal performance and battery life.

Charge the device with the included USB charging cable.

Plug the micro USB end of the charging cable into the DC 5V USB charge port and the USB end into a suitable USB car charger or USB wall charger with DC5V.

Charging time approx. 3 hours, when connected to a standard USB port.

### Get the unit ready to use:



Step 1: Aimed the clip to into the slote.

Step 2: Clip on the car sun visor for ready to use.

### Power On/Off










1. To turn the unit on, press and hold the power switch button 3s to turn ON. The blue LED will light up.
2. To turn the unit off, press and hold the power switch button 3s to OFF. The LED will switch off.

## Pairing a Bluetooth device for the first time

1. Switch on the unit on, press the Play/Pause button for 1 second to bluetooth mode. The LED will flashing in Red/Blue.
2. Turn on your mobile phone Bluetooth function. refer to the user manual for instructions on pairing and connecting Bluetooth devices.
3. Search the Bluetooth device name 'KM42747666" in your Bluetooth settings menu and to select to pair.
4. When successfully paired and connected, a connect tone will be heard.  
After initial paired, the unit will stay paired unless unpair manually by the user.
3. If your device asks for a password, use "0000" or "1234" to complete the pairing

NOTE: Should your device become unpaired or you are not able to connect it, repeat the above steps.

## Operation Guide:

Operation Guide	BT Hands free kit
1.How to play and stop	Short press "  " to Pause/Play
2.How to adjust the Volume	Long Press "  " to increase the Volume. Long press "  " to decrease the Volume.
3.How to choose music	Short Press "  "to play the next song. Short Press "  " to play the previous song;
5.How to use the Hands-free function	Press "  " to answer/ reject the phone call. Press "  " twice to redial the last phone call Long Press "  " to reject when the incoming call.
6.How to transfer the call between BT device and mobile phone.	Short Press "  " to transfer the call between BT device and mobile Phone.
7.How to charge for a device.	Plug into the USB port directly.

**Specification:**

Bluetooth version: 5.0  
Working Voltage: 3.3-4.2V  
Input: 5V d.c. 500mA  
Frequency : 20Hz-15Khz  
Build-in Rechargeable battery  
Charging time up to 3 hours

**12 Month Warranty**

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or alternatively, via Customer Help at [Kmart.com.au](http://Kmart.com.au) for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.