












Assembly Instructions

42918738 CHROME 10 DRAWER TROLLEY

Warning: Load drawer evenly to prevent from tipping over. This package contains small parts and sharp points, keep unassembled parts away from children and babies.

Maximum loading: 2kg each tier.



A		8
B		10
C		10
D		4
E		10
F		1
G		2
H		4
I		1