

170x124mm



anko  
User manual

Insect Zapper

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. The appliance is to be kept out of reach of children. The appliance is not to be used in locations where flammable vapour or explosive dust is likely to exist.

Users shall wash the metal net in a frequently period, and shall keep the lamp powered off while washing, and use the metal bar with insulation to discharge the net, and after that, use soft brush clean it. Do not keep the product in the water.


It is not suitable for use in barns, stables and similar locations.

**⚡ DANGER: High voltage**

**Warning**

- Do not touch the electric netting.
- Device runs on high voltage.
- Disconnect power prior to cleaning or moving.
- NEVER insert metal objects into the grid.
- Do not disassemble the product. There are no user serviceable parts.
- Do not use near explosives or naked flames.
- Do not use near water.
- Keep out of reach of children.
- If damaged, the power cord must be replaced by a qualified technician.
- Product is for indoor use only.

**One. Shape and part name**



**Technical Specification**

Power: AC 220V-240V~50-60 HZ; Net voltage; More than 1500-1800V DC

Resistance : Less than 500Ω; Leakage AMP: 0.1A 220V-240V ~ 50-60HZ

Lamp Life: 6000 hours

**Usage**

1. Please turn on the switch before use.
  2. Product should only be used indoors and away from moisture (bathroom).
  3. Product is designed to be used in room without the light on.
  4. Product is recommended to be hanged higher than 1.2 m from ground and at least 30cm from a wall.
  5. Disconnect power when cleaning. Use a soft clean brush.
- Dispose of environmentally safely if damaged or not wanted.

PRODUCT MODEL:42919698;