

Animal Hopper

Key Code: 42924630

Parts list:

- .Animal Hopper x 1pc
- .Pin x 1pc (inserted in the hole of animal hopper)
- .Pump x1pc

Inflation Instruction:

- .Pull out the pin which is located on the belly of the animal hopper.
- .Gently insert the plastic nozzle of the pump into the inflation hole of product vertically.
Please be careful not to puncture through the other side of the toy while inserting.
- .Inflate product until it is fully inflated.
- .Pull out the nozzle of the pump from the hole, then insert the pin into the hole quickly so no air escapes.

Warning:

1. Adult assembly required. All operations involving inflation must be done by adults.
2. Maximum user weight:30kg.
3. The pump is not a toy.
4. Not to be used as a flotation device.
5. Ensure there are no pointed or sharp objects in the area of use.
6. To be used under the direct supervision of an adult. Use only on level surface.
7. Ensure that the child has understood the toy's function prior to its use.
8. The toy should be used with caution since skill is required to avoid falls or collisions causing injury to the user or third parties.
9. This toy must be used in open spaces, away from obstacles such as furniture, windows, steps, benches and anything else that might cause injury due to impact of falling.
10. Do not use on public roads, at the poolside, or on slippery surfaces.
11. Never attempt to have more than one person on the product at one time.
12. Do not over inflate the item.
13. Do not leave in the sun. High temperatures can alter the item and even make it unfit use.

Care Instruction

- . Wipe clean with damp cloth, do not use abrasive material or solvents.
- . Ensure the item is clean and dry thoroughly before storage.
- . Always store in a dry place when not in use.

Made in China