

DOUBLE SIDED INSTRUCTION SHEET
145W x 200H mm

anko

Light Up Foam Gingerbread House

- › assembled size: 26cm(H) x 18cm(W) x 20cm(D)
- › 22 x foam house pieces
- › 1 x light up foam base
- › assorted decorative adhesive foam shapes


INSTRUCTIONS:

Adult supervision is required.

1. Ask an adult to insert 2 x AA batteries into the light-up foam base.
2. Join the brown pieces together starting with the floor, sides, front and back.
3. Assemble the roof pieces and place the red window in place. Join the constructed roof to the house. Place the red door and windows in place.
4. Fold the chimney and stick together before sitting on top of the roof.
5. Decorate your gingerbread house with adhesive foam pieces as shown on the box packaging or as desired. Peel off the adhesive film off the back of each piece and stick in place.
6. When you are finished decorating, switch on your light under the base of the house and see your gingerbread house light up!

anko

How to insert and remove the batteries



Battery Information

- › Non-rechargeable batteries are not to be recharged;
- › For electric toys using rechargeable batteries, the batteries should be charged under adult supervision;
- › Different types of batteries or new and used batteries are not to be mixed;
- › batteries are to be inserted with correct polarity (+ and -);
- › exhausted batteries are to be removed from the toy;
- › the supply terminals are not to be short-circuited.