



Instruction

KEYCODE: 42934684


DESCRIPTION: BUILDER TOWN TRAIN SET



01x1



02x1



03x1



04x2



05x2



06x1



07x1



08x1




09x1



10x1



11x2



12x2



13x3



14x4



15x4




16x1



17x1



18x1




19x1




20x1



21x1



22x1



23x1




24x2




25x2




26x14




27x2




28x1




29x1



30x2



31x1



32x2

Age grading: 3+ Years.

Adult assembly required.

WARNING:

- The toy is to be assembled by adult.
- Read all the instructions before assembly and use of the product .
- Take care when unpacking and during assembly.
- Dispose of all packing materials carefully after assembly.
- Regularly check that all fittings remain tight. Tighten if required.
- Inspect the product before assembly and periodically during use. Never use this product if there is any loose or missing fasteners, joints or broken parts.
- Never substitute parts.

CHOKING HAZARD: Contains assembly components that are small parts with functional sharp points and edges. Keep away from children under the age of 3 years.

Tracks assembly diagram

