

Assembly Instructions

42940319 COCOON CHAIR




CARE INSTRUCTIONS:


WIPE CLEAN WITH A SOFT DAMP CLOTH. DO NOT USE ABRASIVE MATERIAL AND SOLVENTS. KEEP AWAY FROM WATER AND DIRECT SUNLIGHT. CHECK AND TIGHTEN ALL PARTS REGULARLY. FOR DOMESTIC USE ONLY.

WARNING:








DO NOT STAND ON THE CHAIR. USE ONLY ON A FLAT SURFACE. FOR ONE PERSON USE ONLY. DO NOT USE UNTIL ALL SCREWS, BOLTS AND KNOBS ARE FIRMLY SECURED. THIS PRODUCT CONTAINS SMALL PARTS AND SHARP POINTS, KEEP AWAY FROM CHILDREN AND BABIES. ADULT ASSEMBLY REQUIRED. FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY. **MAXIMUM SAFE LOAD: 100 KG.**

Hardware list


| | | | |
|---|---|--------|-------|
|  | A | 6X35mm | 4PCS |
|  | B | 6X20mm | 16PCS |
|  | C | | 1PC |




Do not tighten the screws fully during assembly.
Fully tighten screws after the final assembly steps

| | | |
|---|--|--|
|  |  |  |
| ① 1PC | ② 1PC | ③ 2PCS |
|  |  |  |
| ④ 2PCS | ⑤ 1PC | ⑥ 2PCS |
|  | | |
| ⑦ 1PC | | |

STEP 1  X16



STEP 2  X4



You can make the whole product more stable by adjusting the knob on the bottom of the foot tube

STEP 3

