

















Assembly Instructions



A: Back Panel X 1 	B: L&R Side Panel X 2 	C: Door Panel X 1 	D: Top Panel X 1 	E: Shelf X 1 	F: Bottom Panel X 1 	G: Back Beam X 1 	H: Front Beam X 1 
I X 4 	J X 1 	K X 1 	L X 4 	N X 6 	M X 1 	O X 1 	

<p>Step 1</p>	<p>Step 2</p>	<p>Step 3</p>	<p>Step 4</p>	<p>Step 5</p>
<p>Step 6</p>	<p>Step 7</p>	<p>Step 8</p>	<p>Step 9</p>	<p>Step 9</p>

CARE INSTRUCTIONS:

Ensure you have all parts before assembling. Put all part on soft surface such as a carpet when assembling.

Wipe clean with a soft dry or damp cloth. Keep away from water and direct sunlight. For indoor and domestic use.

Check and tighten all parts regularly.

WARNINGS:

Do not stand or sit on the unit. Do not lean on the product. Do not drag the product. Use only on a flat surface.

Do not use until all screws, bolts and knobs are firmly secured. This product contains small parts and sharp points, keep away from children and babies. Adult assembly required. Failure to follow these warnings could result in serious injury.

Max loading weight: 10kg each shelf.