

INSTRUCTION MANUAL

42967279
[KMT081]

Chocolate/Black

5107_MAN_42967278_ACS120_BT_TanBlack_v10


Artwork Proof Date: 17.11.2020

Number of artboards: 1

PAPER:


80gsm
Bright white uncoated paper

PRINT COLOURS:



PRINT FINISH:

Double sided
Folded in the centre



CHANGE LOG CREST INTERNAL USE ONLY

ARTWORK SHOULD NOT BE AMENDED WITHOUT PRIOR AGREEMENT FROM CREST.
ALL ARTWORK MUST BE APPROVED BY CREST PRIOR TO MASS PRODUCTION.

IF THERE ARE QUERIES ABOUT THIS ARTWORK PLEASE CONTACT:
EMAIL: design@crest.com.au

THANK-YOU.

© The Crest Company 2020. All rights reserved.

12 month warranty

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with the accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on **1800 124 125 (Australia)** or **0800 945 995 (New Zealand)** or alternatively, via Customer Help at **kmart.com.au** for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, Inc., and any use of such marks by KMART AUSTRALIA is under licence.



WARNING Do not dispose of unit in fire or water. > Never attempt to disassemble and reassemble. > Waste electrical products should not be disposed of with household waste, please recycle where facilities exist. > Check with your local authority for recycle advice. > Keep your device and all accessories out of the reach of children and animals. > Small parts may cause choking or serious injury if swallowed. > Avoid exposing your device to very cold or very hot temperatures (below 0°C or above 45°C). > Extreme temperatures can cause deforming of the device and reduce the charging capacity and life of your device. > Do not allow your device to get wet—liquids can cause serious damage. > Do not handle your device with wet hands. > High sound pressure > Hearing damage risk > Do not listen at high volume levels for long periods.

5107/10

anko

Bluetooth® Headphones Operating Instructions



- includes:
- > Bluetooth® headphones
 - > charging cable
 - > audio cable




42-967-279

Bluetooth name is KM42967279

This product shall be supplied by a power source not exceeding PSI only. > This Bluetooth headphone shall be charged by the supplied charging unit only. **CAUTION** > The batteries in this product are not replaceable. > During use, storage or transportation the battery should not be subjected to extremely low temperatures, or low air pressure at high altitude. > If the battery is exposed to extremely high temperatures it could result in an explosion or the leaking of flammable liquid or gas. > Please take care when disposing of the unit; disposal in a fire, oven, mechanically crushing or cutting machine could result in the battery exploding.

Function overview:



How to use these headphones:

Power ON

Press and hold the M/⊙ button

Power OFF

Press and hold the M/⊙ button

Play Press ►|/∨ button

Pause Press ►|/∨ button

Previous Track

Press the |◀/∨+ button

Next Track

Press the ►|/∨- button

Volume Up Press and hold the |◀/∨+ button

Volume Down Press and hold the ►|/∨- button

Answer Call Press the ►|/∨ button

Decline an Incoming Call Press the ►|/∨ button twice to decline the call

End Call Press the ►|/∨ button

Redial Last Call Press the ►|/∨ button twice in quick succession to call the last dialled number

Activate Siri or Voice Assistant

Press and hold the ►|/∨ button for approx. 3 seconds to activate the voice assistant on your mobile phone

Pairing the headset with Bluetooth devices

- > Once the headphone is powered on, it is in pairing mode (LED flashes blue and red alternately) and will pair to the last paired device (if available).
- > Pair the headset in the Bluetooth menu on the mobile phone and once it is paired, you will hear a pairing tone and the blue LED will flash very slowly. **Bluetooth Name: KM42967279.**

Phone calls

- > Press the power button to pick up/hang up phone calls.
- > Press the power button twice in quick succession button to call the previous number dialed.

Playing music

- > When the headset connects with the mobile phone via Bluetooth you can enjoy music through the headset wirelessly.

TF Card Player

Insert TF card (up to 32GB, TF card not included) into the TF card slot, the music on TF card will automatically be played by the headphone.

When a TF card is inserted, the Bluetooth function of headphone will temporarily turn off, the headphone will no longer be connected to the mobile phone, and cannot be used to make or answer calls through the headphones.

Aux Mode

When headphone is in Bluetooth mode, insert the Aux audio cable into the headphone, the Bluetooth function will turn off and switch to Aux mode, connect the opposite end to the phone/computer or other device with 3.5mm jack, then you can make or answer phone calls or enjoy music through the headphones.

Battery Charging

This Bluetooth headphone is powered by rechargeable Li-ion battery. Please use the supplied USB cable to charge the battery.

- > Insert USB charging cable into a suitable USB port.
- > Connect charging cable with the headphone USB port.
- > Indicator LED turns RED to show battery is charging.
- > Indicator LED turns OFF when battery is fully charged.
- > It takes approximately 2.5 hours to fully charge the battery.
- > When there is no music played for 30 seconds the headphone will automatically go to power save mode and will switch off when the battery is low.

Specifications:

Model no: 42967279

Version: V5.0

Support profiles: A2DP, AVRCP, HFP

Working distance: 10 Metres

Music time: Approx. 10 hours

Talk time: Approx. 10 hours

Standby time (powered): Approx. 100 hours

Charging voltage: 5V d.c.

Battery capacity: 450mAh

Charge time: Approx. 2.5 hours

Pairing time window: 5 minutes