

# INSTRUCTION MANUAL

42968313  
[KMT081]

Black

5107\_MAN\_42968313\_ANC100\_BT\_Black\_v7

Artwork Proof Date: 17.09.2020

## PAPER:

80gsm  
Bright white uncoated paper

## PRINT COLOURS:

BLACK

C:0 M:0  
Y:0 K:100

## PRINT FINISH:

Double sided  
Folded in the centre




## CHANGE LOG CREST INTERNAL USE ONLY

ARTWORK SHOULD NOT BE AMENDED WITHOUT PRIOR AGREEMENT FROM CREST.  
ALL ARTWORK **MUST** BE APPROVED BY CREST PRIOR TO MASS PRODUCTION.

IF THERE ARE QUERIES ABOUT THIS ARTWORK PLEASE CONTACT:  
EMAIL: design@crest.com.au

THANK-YOU.

 © The Crest Company 2020. All rights reserved.

## 12 Month warranty

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with the accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on **1800 124 125 (Australia)** or **0800 945 995 (New Zealand)** or alternatively, via Customer Help at **kmart.com.au** for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, Inc., and any use of such marks by KMART AUSTRALIA is under licence.




**WARNING** Do not dispose of unit in fire or water. › Never attempt to disassemble and reassemble. › Waste electrical products should not be disposed of with household waste, please recycle where facilities exist. › Check with your local authority for recycle advice. › Keep your device and all accessories out of the reach of children and animals. › Small parts may cause choking or serious injury if swallowed. › Avoid exposing your device to very cold or very hot temperatures (below 0°C or above 45°C). › Extreme temperatures can cause deforming of the device and reduce the charging capacity and life of your device. › Do not allow your device to get wet—liquids can cause serious damage. › Do not handle your device with wet hands. › High sound pressure › Hearing damage risk › Do not listen at high volume levels for long periods.

5107/7

This product shall be supplied by a power source not exceeding PS1 only. › This BT headphone shall be charged by the supplied charging unit only.  
**CAUTION** › The batteries in this product are not replaceable. › During Use, Storage or Transportation the battery should not be subjected to extremely low temperatures, or low air pressure at high altitude. › If the battery is exposed to extremely high temperatures it could result in an explosion or the leaking of flammable liquid or gas. › Please take care when disposing of the unit; disposal in a fire, oven, mechanically crushing or cutting machine could result in the battery exploding.

## Function overview:



### How to use these headphones:

#### Function Operation:

Play: Press ►|| button

Pause: Press ►|| button

Previous Track: Press ←◀ button

Next Track: Press ►▶ + button

Answer Call: Press ►|| button

End Call: Press ►|| button

Reject call: Press and hold ►|| button for approx. 1 second

Redial Last Call: Press ►|| button twice

Activate Phone Assistant: Press ►|| button 3 times

anko

# Bluetooth® Headphones Quick start guide



includes:

- › Bluetooth headphones
- › charging cable
- › audio cable



42-968-313

Bluetooth name is KM42968313

Volume Up: Press and hold ►▶ + button

Volume Down: Press and hold ←◀ button

ANC Function ON: Slide ON/OFF button to turn on ANC

ANC Function OFF: Slide ON/OFF button to turn off ANC

Power ON: Press and hold the power ►|| button for approx. 1 second until blue LED is on

Power OFF: Press and hold the power ►|| button for approx. 1.5 seconds until the LED starts to flash, then goes off

### Pairing the Headphone with Bluetooth Devices

- › Once the headphone is powered on, you will hear a voice prompt "Power on, ready to pair", the headphone will then pair to the last paired device.
- › If not previously paired, search on your electronic device's Bluetooth menu and select the pairing name **KM42968313**.
- › Once connected you will hear a voice prompt "Device Connected".
- › To shut down the Bluetooth function on the current connected device, the headphone will go to pairing mode again with red and blue LED flashing and is available to be connected with a different device.

### Aux Mode

When the headphone is in Bluetooth mode, insert the Aux audio cable into the headphone, the bluetooth headphone will turn off and switch to Aux mode, connect the opposite end to the phone/computer or other device with 3.5mm jack, then you can phone call or play music etc.

### Battery Charging

- › Please use the provided USB cable to charge the battery
- › Insert the micro USB cable end into the headphone charging port
- › Insert USB charging cable into an appropriate 5V 1A USB port
- › The LED will turn red when charging and turn blue when the headphone is fully charged
- › It takes max 4 hours to fully charge the battery

## Specifications:

**Model No:** 42968313

**Version:** V5.0

**Working distance:** 10 Metres

**Music time:** approx. 15 hours

**Talk time:** approx. 13 hours

**Standby time (powered - Bluetooth mode):** approx. 45 hours

**Charging voltage:** 5V d.c.

**Battery capacity:** 400mAh

**Charge time:** Max. 4 hours

**Pairing window time:** 5 minutes