## **Assembly Instruction** 42974055 Wood Look Storage Bench

## **CARE INSTRUCTIONS:**

WIPE CLEAN WITH A DRY CLOTH.DO NOT USE ABRASIVE MATERIALS AND SOLVENTS.CHECK AND TIGHTEN ALL PARTS REGULARLY.DO NOT PLACE HOT ITEMS SUCH AS COFFEE CUPS DIRECTLY ON THE SURFACE.KEEP AWAY FROM WATER AND DIRECT SUNLIGHT.STORE IN A DRY PLACE.FOR DOMESTIC USE ONLY.FOR INDOOR USE ONLY.A MILD ODOUR MAY BE PRESENT WHEN FIRST OPENING THIS CARTON.SIMPLY ALLOW TO AIR OUTSIDE AND THIS WILL FADE.

## **WARNING:**

DO NOT STAND ON THIS UNIT. DO NOT USE THIS UNIT UNLESS ALL BOLTS AND SCREWS ARE FIRMLY SECURED.DO NOT KNOCK OR DRAG THIS UNIT.USE ONLY ON A FLAT SURFACE.ADULT ASSEMBLY REQUIRED.FAILURE TO FOLLOW THESE WARNING COULD RESULT IN SERIOUS INJURY.TNIS PACKAGE CONTAINS SMALL PARTS AND SHARP POINTS.KEEP AWAY FROM CHILDREN AND BABIES.

MAXIMUM SAFE LOAD: 70KG FOR SEATER,5KG FOR EACH CABINET.

## **Hardware List**

	а	M4x35mm	20pcs
	b	Ø 6x30mm	21pcs
8	С	M2x16mm	12pcs
0	d		2pcs
	е		4pcs
•	f	M3x12mm	10pcs

	g		2pcs
~	h	M3x14mm	4pcs
***************************************	i	M4x45mm	4pcs
-	j	M4x18mm	4pcs
0	k		16pcs
<b>\oint_{\int_{\intt_{\int_{\int_{\inttilent_{\int_{\int_{\inttilent_{\inttilent_{\inttilent_{\inttilent_{\inttilent_{\inttilent_{\inttilent_{\inttilent_{\inttilent_{\inttilent_{\inttilent_{\intilent_{\inttilent_{\inttilent_{\inttilent_{\inttilent_{\inttilent_{\inttilent_{\inttilent_{\inttilent_{\inttilent_{\inttilent_{\intilent_{\inttilent_{\inttilent_{\intilent_{\inttilent_{\inttilent_{\intilent_{\inttilent_{\inttilent_{\intilent_{\intilent_{\intilent_{\intilent_{\intilent_{\intilent_{\inttilent_{\intiilent_{\intilent_{\intilent_{\intiilent_{\intilent_{\intilent_{\intilent_</b>	1	Ø 6x15mm	4pcs









