

Assembly Instruction

42976158 KIDS BUCKET CHAIR

Please read instructions carefully. Be sure you have all parts before you begin to assemble. Assemble furniture on a clean, flat surface such as carpet to avoid any abrasion.

Tools required: Hex Key (included).

Care instruction:

Wipe clean with a soft damp or dry cloth. Do not use abrasive cleaners.


Warning:

Max. safe loading: 50kgs.

Choking hazard – small parts.

Not for children under 3 years.

Parts:



replace this with: fix the legs (e) to the seat (d) with the washer (a) and screws (b). Tighten all screws with the hex key (c) as per the diagram and then assembly is complete.

