


# STUNT DRAGON

**3+**  
YEARS


## Installing batteries in the remote control:

- 1 - Open the battery compartment.
- 2 - Insert 2 x 1.5V AAA batteries with the correct + and - polarities.
- 3 - Close the cover.




## Installing the vehicle battery:

**Fig 1:**




1. Loosen the screw and open the battery cover.

**Fig 2:**



2. As shown in figure, remove the battery cover and insert 4 x 1.5V AAA batteries with correct + and - polarities, and then close the cover.

**Fig 3:**





## How to use:



1. Turn on the vehicle and then turn on the remote control.
2. When the vehicle is functioning, this means they have matched.
3. If you have more than two vehicles, please pair one by one. When the second vehicle is pairing, please always keep the first vehicle and transmitter on.
4. Please turn off both the vehicle and transmitter and re-start all pairing processes if you are changing to play with another 2.4GHz transmitter.

## Start:





1. How to move forwards or backwards:  
Push both levers up, the vehicle will move forwards. (see Diagram 1)  
Push both levers down, the vehicle will move backwards. (see Diagram 2)





2. How to swerve left or right:  
Push the right lever up, the head will swerve left. (see Diagram 3)  
Push the left lever up, the head will swerve right. (see Diagram 4)



3. How to rotate 360 degrees:  
Push the left lever up and right lever down simultaneously, the vehicle will rotate clockwise. (see Diagram 7)  
Push the left lever down and right lever up simultaneously, the vehicle will rotate anticlockwise. (see Diagram 8)



4. How to flip up:  
When the vehicle is tipped-over to left, push the left lever up (down) for a few seconds and then push it down (up) and hold on until the vehicle flips up. (see Diagram 9)  
When the vehicle is tipped-over to right, push the right lever up (down) for a few seconds and then push it down (up) and hold on until the vehicle flips up. (see Diagram 10)



Attention: Use stunt dragon on a hard, smooth floor for better flip up function performance.

WARNING: BATTERIES ARE TO BE INSERTED WITH THE CORRECT POLARITY (+ and -). DO NOT MIX DIFFERENT TYPES OF BATTERIES OR NEW AND USED BATTERIES. NON-RECHARGEABLE BATTERIES ARE NOT TO BE RECHARGED. RECHARGEABLE BATTERIES ARE ONLY TO BE CHARGED UNDER ADULT SUPERVISION. RECHARGEABLE BATTERIES ARE TO BE REMOVED FROM THE TOY BEFORE BEING CHARGED. THE SUPPLY TERMINALS ARE NOT TO BE SHORT-CIRCUITED. REMOVE BATTERIES FROM THE TOY WHEN NOT IN USE FOR EXTENDED TIME OR WHEN BATTERIES BECOME EXHAUSTED. BATTERY INSTALLATION BY AN ADULT IS REQUIRED. DISPOSE OF BATTERIES RESPONSIBLY. DO NOT DISPOSE OF IN FIRE.

WARNING: FOR SAFETY REASONS REMOVE ALL TAGS, LABELS AND PLASTIC FASTENERS BEFORE GIVING THIS TOY TO YOUR CHILD.

**WARNING:**  
CHOKING HAZARD  
SMALL PARTS. NOT FOR  
CHILDREN UNDER 3 YEARS.

\* PRODUCT MAY VARY SLIGHTLY FROM IMAGE SHOWN.  
\* PLEASE KEEP THE PACKAGING FOR FUTURE REFERENCE.  
\* PERFORMANCE TIPS: DO NOT DRIVE THE VEHICLE THROUGH WATER. DO NOT DRIVE THE VEHICLE INTO ANY HARD OBJECT.

**2.4GHz**  
MADE IN CHINA  
Z516  
FOR AU / NZ: IMPORTED FOR KMART  
STORES IN AUSTRALIA AND NEW ZEALAND. Keycode: 42982258