## **INSTRUCTION MANUAL**

43001170

[KMT081]

5107 MAN 43001170 XYBT154 BT Headphones V5

Artwork Proof Date: 12.11.2020 Number of artboards: 1

PAPER:


Bright white uncoated paper

#### **PRINT COLOURS:**



#### **PRINT FINISH:**


Double sided Folded in the centre



## CHANGE LOG CREST INTERNAL USE ONLY

ARTWORK SHOULD NOT BE AMENDED WITHOUT PRIOR AGREEMENT FROM CREST. ALL ARTWORK MUST BE APPROVED BY CREST PRIOR TO MASS PRODUCTION. IF THERE ARE QUERIES ABOUT THIS ARTWORK PLEASE CONTACT: EMAIL: design@crest.com.au

THANK-YOU.



# anko

Includes:

### 12 month warranty

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with the accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or alternatively, via Customer Help at kmart.com.au for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, Inc., and any use of such marks by KMART AUSTRALIA is under licence.



WARNING Do not dispose of unit in fire or water. > Never attempt to disassemble and reassemble. > Waste electrical products should not be disposed of with household waste, please recycle where facilities exist. > Check with your local authority for recycle advice. Yeep your device and all accessories out of the reach of children and animals. Small parts may cause choking or serious injury if swallowed. > Avoid exposing your device to very cold or very hot temperatures (below 0°C or above 45°C). > Extreme temperatures can cause deforming of the device and reduce the charging capacity and life of your device. > Do not allow your device to get wet—liquids can cause serious damage. > Do not handle your device with wet hands. > High sound pressure > Hearing damage risk > Do not listen at high volume levels for long periods.

# Bluetooth® On-Ear Headphones Operating instructions




43-001-170

Bluetooth name is KM43001170

This product shall be supplied by a power source not exceeding PS1 only. This BT headphone shall be charged by the supplied charging unit only. CAUTION . The batteries in this product are not replaceable. Use, storage or transportation the battery should not be subjected to extremely low emperatures, or low air pressure at high altitude. If the battery is exposed to extremely high temperatures it could result in an explosion or the leaking of flammable liquid or gas. > Please take care when disposing of the unit; disposal in a fire, oven, mechanically crushing or cutting

### How to use these headphones:



### **Function Operation:**

Play: Press ►II button Pause: Press ►II button Previous Track: Press —◀◀ button **Next Track:** Press ▶ + button **Answer Call:** Press ►II button End Call: Press ►II button **Reject Call:** Press and hold ►II button for approx. 2 seconds

Redial Last Call: Press ►II button twice Activate Phone Assistant: Press and hold MODE button for approx. 2 seconds **Volume Up:** Press and hold ▶▶+ button **Volume Down:** Press and hold —◀◀ button Power ON: Slide ON/OFF button to power ON

Power OFF: Slide ON/OFF button to power OFF

Pairing the headset with Bluetooth devices

- Once the headphone is powered on, you will hear a voice prompt "Power On", the headphone will then pair to the last paired device.
- > If not previously paired, search on your electronic device's Bluetooth menu and select the pairing name KM43001170.
- Once connected you will hear a beep sound a voice prompt "The Bluetooth device is connected successfully".
- > To shut down the Bluetooth function on the connected device, the headphone will go to pairing mode again with red and blue LED flashing and is available to be connected with a different device.

### **Aux Mode**

To switch to Aux mode, insert the Aux Cable into the headphone, and the 3.5m Jack end into your mobile device or computer. Bluetooth mode will automatically switch off.

### **Battery Charging**

- > Please use the provided USB cable to charge the battery.
- > Insert the micro USB cable end into the headphone charging port.
- > Insert USB charging cable into an appropriate 5V 1A USB port.
- > The LED will turn red when charging and turn blue when the headphone is fully charged.
- > It takes max 3 hours to fully charge the battery.

### **Specifications:** Model no: 43001170

Version: V5.0 Support profiles: A2DP1.3/HFP1.6/HSP1.2/AVRCP1.6 Working distance: 10 Metres Music time: Approx. 10 hours

Talk time: Approx. 10 hours **Standby time (powered):** Approx. 30 hours Charging voltage: 5V d.c. Battery capacity: 300mAh Charge time: Approx. 3 hours Pairing window time: 5 minutes