

## 12 month warranty

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with the accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on **1800 124 125 (Australia)** or **0800 945 995 (New Zealand)** or alternatively, via Customer Help at **kmart.com.au** for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

**WARNING** Do not dispose of unit in fire or water. › Never attempt to disassemble and reassemble. › Waste electrical products should not be disposed of with household waste, please recycle where facilities exist. › Check with your local authority for recycle advice. › Keep your device and all accessories out of the reach of children and animals. › Small parts may cause choking or serious injury if swallowed. › Avoid exposing your device to very cold or very hot temperatures (below 0°C or above 45°C). › Extreme temperatures can cause deforming of the device and reduce the charging capacity and life of your device. › Do not allow your device to get wet—liquids can cause serious damage. › Do not handle your device with wet hands.

# Bluetooth® Metallic Headphones


## Operating instructions

includes:

- › Bluetooth Metallic Headphones
- › Charging cable
- › Headphone audio cable



## Function overview:



## How to use these headphones:


### Function Operation

**Pause:** short press  button

**Play:** short press  button

**Next song:** short press  button


**Previous song:** short press  button

**Volume up:** long press  button  
when the volume is adjusted to maximum  
you will hear a indication tone


**Volume down:** Long press  button

### Power ON / OFF

#### Power on:

press  button, you will hear: pairing



#### Power off:

press  button, until you hear: power  
off, the blue LED goes out

### Pairing the headset with Bluetooth devices

- › Once the headphone is powered on, it is in pairing mode (LED flashes slowly) and will pair to the last paired device (if available).
- › Pair the headset in Bluetooth menu in mobile phone and once it is paired, you can hear a pairing tone and the LED will flash very slowly.  
Bluetooth Name: **KC43030675**

### Phone calls

- › Press  button to pick up/hang up phone calls.
- › Double press the  button to call the previous number dialed.

### Playing music

When the headset connects with the mobile phone via Bluetooth you can enjoy music through the headset wirelessly.

Alternatively you can connect the headphone cable and listen to music when the cable is connected directly to your music device via its headphone input. This function can still be used when the headphones battery is flat.

### Battery Charging

This Bluetooth headset is powered by rechargeable Li-ion battery.

Please use the accessory USB cable to recharge the battery.

- › Insert USB charging cable into a suitable USB port.
- › Connect charging cable with the headset USB port .
- › Indicator LED turns RED to show battery is charging.
- › Indicator LED turns OFF when battery is fully charged.
- › It takes about 1 hours to fully charge the battery.

## Specifications:

**Model No:**  
43030675

**Version:**  
V5.0 multimedia hi-fi Bluetooth  
chipset

**Support profiles:**  
A2DP, AVRCP, HFP

**Working Distance:**  
10 meters

**Music Time:**  
>6 Hours

**>Talk time:**  
>10 Hours

**Standby  
time:**  
>100 Hours

**Charging voltage:**  
5V d.c.

**Charge time:**  
1 Hours

**Pairing window time:**  
5 minutes

**Non-play automatic power save mode:**  
after 30 seconds the headphone will enter power save mode and then automatically switch off when the low battery alarm sounds.