


风琴折

128g双铜双面四色印刷

105*148.5mm

封面

封底



anko


Premium Gaming Headset

Operation instructions

43-030-583

Please read all the information carefully before you use the product and keep the manual for future reference.

Product Spec:
 Speaker: Φ53mm
 Impedance: 64±15%Ω
 Sensitivity: 98dB±3dB
 Frequency Response: 20Hz to 20KHz
 Microphone: Ø6.0*2.7mm
 Microphone sensitivity: -42±3dB
 Cord length: 2.1m±10%
 Plug: stereo and USB
 Input power: 5V/160mA




1. Volume+ button
Press this button to increase the volume
2. Volume- button
Press this button to decrease the volume or volume mute
3. Microphone mute button
Press this button to mute microphone volume
4. RGB light switch button
Press this button to change 5 kinds of light effects. (Colorful Streaming mode / Neon mode/ Breathing mode / Colorful Steady mode/ LED off)

Features:


1. Built in high magnetic 53mm speaker, high end sound experience.
2. High imitation protein leather earmuffs, more comfortable for long time wearing.
3. Suspended adjustable single-head beam and metal steel frame, ergonomic and anti-violence design.
4. Virtual 7.1 USB surround sound effects, different sound effects and scenes can be adjusted through the software.

Connecting the Headphone



Insert it into the USB ports of the computer. If you use a desktop computer, it is best to plug it into the USB ports on the back of the computer case instead of the USB ports on the front.

"For more sound effects and scenes, please enter "<http://www.intraindustry.com/downloads.html>" to download the software:



12 month warranty

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with the accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or alternatively, via Customer Help at kmart.com.au for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.


WARNING: Do not dispose of unit in fire or water. • Never attempt to disassemble and reassemble. • Waste electrical products should not be disposed of with household waste, please recycle where facilities exist. • Check with your local authority for recycle advice. • Keep your device and all accessories out of the reach of children and animals. • Small parts may cause choking or serious injury if swallowed. • Avoid exposing your device to very cold or very hot temperatures (below 0°C or above 45°C). • Extreme temperatures can cause deforming of the device and reduce the charging capacity and life of your device. • Do not allow your device to get wet—liquids can cause serious damage. • Do not handle your device with wet hands.

(3)music sampling frequency



Note: select the same sampling frequency with the music to gain better audio quality

(4)equalizer



Click to open the equalizer

(5)environment effects



environment effects on/off switch
more choice of environment mode
The size of the room
The environment mode

(6)7.1 virtual sound control



7.1 virtual sound control switch
surround size adjustment

(7)the tone setting



the original tone switch
original sound elimination switch
the switching state model
Volume control bar
the eliminate the control bar

(8)Xear surround sound



surround sound switch

THE MICROPHONE SETTINGS

(1) the microphone volume control



the microphone volume control
the microphone monitor volume control
the microphone mute switch
the microphone monitor mute switch

(2) the sampling frequency settings



(3) Kara OK magic sound selection



microphone echo switch
magic sound effect switch
the monster sound simulation
simulation cartoon sound

(4)Microphone volume enhancing settings



Microphone volume enhancing switch

the driver version information



basic settings

