

# anko

## Instruction manual

### Vlogging Starter Kit


Keycode: 43030651

#### Safety Instructions:

Please read the instruction manual before using this device and follow all the safety instructions to avoid damage caused by improper use.

1. Keep the device away from all hot surfaces and naked flames.
2. Do not immerse the device in water or in other liquids.
3. Do not use the device in wet conditions.
4. Do not use the tripod in windy conditions or on an uneven surface.
5. Do not use the device if it is damaged.
6. This device is not a toy. Children should be supervised to ensure they do not play with the device.

#### Features:



## **Technical Data**

Power supply: 2 x AAA batteries (Not included)

Support devices up to 6.5 inch.

## **Instruction**

1. Insert the 2 x AAA batteries (not included) into the battery compartment inside the back of the LED light, Ensure the polarity of the batteries match the polarity inside the battery compartment.
2. Mount the phone clip on the tripod stand.
3. Adjust the width/length and place your smart phone in the phone clip.
4. Hold the stick or unfold the tripod to place it on a flat surface.
5. Press the ON/OFF button to turn on/ off / switch LED brightness level (High-Medium-Low).