

# INSTRUCTION FOR DIGITAL COIN COUNTER JAR

This ingenious money jar, electronically counts every coin as it slips through the slot, then sums up your total Coin and displays them on the easy-to-read LCD screen. Say goodbye to manual counting!

## Features:

- large LCD
- Reset switch
- Permanent memory function



1. Open the coin counter lid



2. Unscrew the battery door



3. Put 2AA batteries into the battery compartment and screw the battery door shut



4. Reset switch



5. Insert coins into the slot of the coin counter jar

Problem	Possible Causes	Probable solutions
No reading on LCD	1. Check if there are any batteries in battery compartment. 2. Batteries are incorrectly placed in digital coin counter jar battery compartment or they are low power need to be replaced.	Check batteries and replace with new, fresh batteries if necessary, being carefully as to positive/negative positions in battery compartment
Incorrect reading	Incorrect way of inserting the coins into the slot	1. Insert the coins into the slot vertically. 2. Do not retrieve the coins when inserts the coins into the slot.