



User Manual

OUTDOOR LIGHT WITH TRIPOD

Keycode: 43089062

Please read all the information carefully before you use the device, keep it for future reference.



Safety instructions:

Please read all safety instruction warnings carefully before using this product. Improper use of this product may result in damage to this or attached products. To ensure the product works well, please never use in the following conditions:

1. Near heaters or in high temperatures.
2. In direct sunshine.
3. Do not use chemical solvents to clean this product.

Specification:

3 ways to power: USB, Car charger, Alligator clip

Input: DC 12V and 5V

Light panel size: 17 * 12 cm

Lumens: 1000

Maximum height of tripod stand in normal use: 270cm.

Separation between tripod stand base feet in normal use: Minimum 94cm.

Angle of inclination of light panel: 0-45 degree

Packing contents:

1.	Tripod stand x1
2.	Car lighter socket x 1
3.	USB to Cigarette lighter x 1
4.	Alligator clip x 1
5.	Wire controller x 1
6.	Remote control x 1 (Require 2 x AAA batteries, not included)
7.	Light panel x1
8.	4M power cord wire x 1
9.	Carry bag x 1



Operating Instructions (3 ways power source)

Preparation: Install the light panel ⑦ into the stand ①. Connect the light panel ⑦ with 4M power cord wire ⑧, then connect the power cord with wire controller ⑤.



1. Cigarette lighter operating: after above preparation process, connect the cigarette ② with the wire controller ⑤, insert the cigarette lighter into the car lighter socket rated DC 12V.
2. USB operating: after cigarette lighter operating process, connect cigarette lighter ② with provided car lighter socket ③, then connect the USB connector with USB port rated DC 5V.
3. Alligator clip: after preparation process, connect the wire controller ⑤ with alligator clip ④, then link the clips with accumulator. Red clip for positive pole, black clip for negative pole.
4. Use the wire controller or remote control to power on and change brightness.



Wire controller:  Press to turn on/off the light.

 Short press to increase the brightness, total 11 brightness, long press for stepless adjustment.

 Short press to lower the brightness, total 11 brightness, long press for stepless adjustment.

Remote Control - 2 x AAA batteries (not included)

 Press to turn on/off the light.

 Short press to increase the brightness, total 11 brightness.

 Short press to lower the brightness, total 11 brightness.

Maintenance

1. Replace batteries in remote control.

Open the door of remote control. Replace batteries with 2 x AAA batteries. Close the door of remote control.

2. Before cleaning, unplug from input source.

Made in China