

# ACHERY TARGET

Key Code: 43105908

## Warning

- **CHOKING HAZARD**, small parts. Not suitable for children under 3 years.
- Do not aim at eyes or face.
- Do not use bows and arrows other than those supplied by manufacturer.
- Adult assembly and supervision required.

## Parts List

- Target board x1pc
- Plastic stand x2pc

## Assembly Instruction

Take out all the parts from packaging, then insert the plastic stands into its position, the product will be assembled successfully.



## Fold Instruction

At the back of target board, there is a space for easy storage of plastic stands. Set the stands at the back of target board firmly according to the guideline.



## Care and Storage Instruction

1. Clean all surfaces gently with a damp cloth when not in use. Don't use solvents or other chemicals that may damage the product.
2. Store in a cool, dry place and out of children's reach.
3. Keep away from open flames and heat sources.

FOR AU/NZ: IMPORTED FOR KMART STORES IN AUSTRALIA AND NEW ZEALAND.

Made in China