













Assembly Instructions

43107537 FLUTED GLASS DRINK TROLLEY

WARNING: Do not stand, sit or lean on the trolley. Use only on a flat surface. Do not use until all screws, bolts and knobs are firmly secured. Do not put very hot or very cold items on the glass surface unless adequately thickness tablemats are used to prevent such items from contacting the glass. Do not use the glass as a chopping surface. Do not strike the glass with hard or pointed items. Do not use washing powder or any other substances containing abrasive scratch the glass surface. This product contains small parts and sharp points, keep away from children and babies. Adult assembly required. Failure to follow these warnings could result in serious injury.

CARE INSTRUCTION: Wipe clean with a soft damp cloth. Do not use abrasive materials solvents. When cleaning the glass surface, use damp cloth with liquid detergent or window cleaner. Check and tighten all parts regularly. Keep away from water and direct sunlight. For domestic use only.
MAXIMUM LOAD WEIGHT OF EACH LAYER: 10kg

 A.X2	 B.X2	 C.X2	 D.X2	
 E.X8	 F.X8	 G.X1	 H.X1	 I.X8
<p>STEP 1</p> 		<p>STEP 2</p> 		
<p>STEP 3</p> 		<p>Fully tighten screws after the final assembly steps.</p> 