

RGB ROCKER GAMING CHAIR User Manual



Model No.: RC-01

How To Use



- Remove RGB Gaming Rocker Chair from the box.
- Unfold the chair and attach the Velcro strip to the rear of the chair, where back rest meets the base.
- Place RGB Gaming Rocker Chair on a smooth and horizontal surface, located near a USB power source.
- The USB power cable is in a pocket right side base of the RGB Gaming Rocker Chair. Insert the USB cable into a power source (such as a USB power adapter or power bank).
- The RGB light sequencing will start automatically.

WARNING!

- DO NOT STAND ON THE CHAIR.
- USE FOR ONE PERSON ONLY.
- DO NOT USE THE CHAIR AS A STEP LADDER.
- TAKE CARE NOT TO GET FINGERS CAUGHT WHEN FOLDING/UNFOLDING THE CHAIR.
- FEET SHOULD REMAIN FIRMLY ON THE GROUND DURING USE.

FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.

Max safe load: 100kg

Important Information

- 1. The USB cable of this chair cannot be replaced; the lighting function will not work if the cord is damaged.
- 2. The LED globes are not replaceable. When the globes reach thier end of life the LED lighting will not work.
- 3. This product works with a DC 5V/2A USB port.
- 4. This product is for indoor use only.

Care Instructions

- Wipe clean with a damp cloth.
- Do not use abrasive materials and solvents.
- · Keep out of direct sunlight.
- Store in a dry place