FRONT COVER

14.85cm

STYLEGUIDE: ANKO-BABY
LOCATION & OPERATOR: HK/KENNETH SO

BACK COVER
14.85cm

anko

GRID UNITS

Care Instructions:

PLAY MAT: COLD HAND WASH. DO NOT TUMBLE DRY. DO NOT IRON. DO NOT DRYCLEAN ⊗.

KEYCODE: 43-112-388

KMART CUSTOMER SERVICE

AU: 1800 124 125 NZ: 0800 945 995


FOR AU / NZ: IMPORTED FOR KMART STORES IN AUSTRALIA AND NEW ZEALAND.

MADE IN CHINA

_

Wooden Activity Gym Instruction Manual







The Product and illustrations shown in this instruction manual are generic.


The manufacturer reserves the right to change any specification or feature without further notice.


IMPORTANT! PLEASE READ CAREFULLY BEFORE USE AND KEEP FOR FUTURE REFERENCE.

INNER FRONT COVER

14.85cm

INNER BACK COVER 14.85cm





WARNING!

- To ensure your child's safety, this product must be assembled by an adult.
- Please keep out of child's reach in unassembled condition.
- Read and follow all the instructions carefully and ensure the final assembly is correct before use of the product. Check frequently.
- Take care when unpacking and during assembly.
- Dispose of all packing materials carefully after assembly.
- Regularly check to ensure all fittings remain tight.
- Inspect the product before each use. Never use this product if there are any loose or missing fasteners or if it is worn or damaged.
- Any additional or replacement parts should only be obtained from the manufacturer or distributor.
- Never substitute parts.
- Product must be used under adult supervision.
- Never leave the child unattended.
- Babies should not be allowed to sleep unsupervised while laying on this play mat.
- Do not lift or attempt to move play mat with baby on it.
- Do not use this product as a blanket.
- Keep away from fire and heat sources. To prevent entanglement injury, never place the play mat in a crib or playpen. Use only on a flat, horizontal floor. Never add additional strings, straps or other products to the play mat.