


## Climbing Net Instruction Manual

includes climbing net, extension webbing straps,  
anchors, carabiner hook and metal U hook set

**6+**  
years  
SWING

**50**  
kg  
MAXIMUM  
WEIGHT



Drawings in the manual are for visual purposes only. Actual product may vary slightly.  
The manufacturer reserves the right to change any specification or feature without prior notice.

**IMPORTANT! PLEASE READ CAREFULLY BEFORE USE  
AND KEEP FOR FUTURE REFERENCE.**

# INSTRUCTIONS ON ASSEMBLY AND USE



## CONGRATULATIONS ON PURCHASING THIS PRODUCT!

Please read these instructions carefully. The instructions are an integral component of the product. Therefore, please store them and the packaging carefully in case questions arise in the future. Please always include these instructions when handing on the product to a third party. This product must be assembled by an adult. This product is designed for domestic use only. This product is not designed for commercial / industrial use. The use of the product requires certain capabilities and skills. Always adjust according to the age of the user and use for the purpose it has been designed for.

Check the product for damage or traces of wear and tear before and after each use.

We also recommend before each use:

- to check for the firm sitting of nuts and bolts and suspensions, tighten if necessary.
- to lubricate moving parts in order to minimize wear.
- to check all covers of screws and sharp edges and replace if necessary.
- to replace defective parts according to the manufacturer's instructions.
- to check swing seats, chains, ropes and other means of attachments for evidence of deterioration.
- Sand rusted areas and tubular members and repaint using a non-lead based paint when required.

Please keep instruction manual for future reference, and it is important that the instruction manual is followed at the beginning of each season as well as at regular intervals during usage.

## SAFETY INSTRUCTION

- **WARNING!** Only for domestic use. For outdoor use only.
- **WARNING!** To be used under the direct supervision of an adult.
- **WARNING!** Not suitable for children under 3 years. Danger of falling!
- **WARNING!** Not suitable for children under 3 years. Long cord. Strangulation hazard.
- The owners of the product as well as the competent supervisory personnel are responsible for ensuring that all users follow the instructions in the operation manual.
- Do not make any technical modifications.
- Changes to the original product must only be carried out according to manufacturer specifications.
- Always hold yourself firmly with both hands.
- No objects of any kind must be in the vicinity of the play zone (trees, walls, fences, clotheslines).
- Clearance to stationary components on the side, such as the swing scaffolding must be at least 40cm.
- Swinging components, such as a neighboring swing must be placed at a distance of at least 60cm.
- Prior to installation, carefully select and check the location where you will install the product. Place the climbing net on a level surface at least 2.5m from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines or electrical wire.
- You should never install the product in such a way that the user could be blinded by sun rays.
- When permanently exposed to UV light, the material ages significantly faster. To avoid premature aging and thereby extend the service life, you should always store the product in a dry and dark place when not in use. Do not permanently expose the product to wind, moisture, extreme temperatures or sunlight.

Kmart

Kmart Australia limited

Kmart Australia-690 Springvale Rd, Mulgrave,

VIC 3170 Australia.

Tel: 1800 124 125

Kmart New Zealand-Regional office

C/O Kmart Papataetoe Store

Hunters Plaza, Great South Rd, Papatoetoe,

Auckland, New Zealand.

Tel: 0800 945 995






Made in China

## HANGING DEVICE AND ADJUSTMENT

The hanging points must be at same width of climbing cargo net or at most as far as the net + 100mm. The climbing cargo net is packaged with four extension webbing straps and carabiner hooks, so that the height of the climbing cargo net can be variably aligned with any suitable hanging device. The climbing cargo net can be lengthed by assembling the extension webbing straps with carabiner hooks. No one should climb the cargo net while making the adjustments.

## MAINTENANCE AND STORAGE

Use a dry or damp cloth only to clean the product; do not use special cleaning agents! Check the product for damage or traces of wear and tear before and after each use. If checks are not carried out this may lead to a hazard. Do not make any structural changes. If parts become damaged or if sharp edges or corners should develop, the product may not be used any more. Please replace damaged parts when necessary. Store the product in a safe place where it is protected from the elements, cannot be damaged, and cannot injure anyone.

NO.	PART	DESCRIPTION	QTY
A		Carabiner hook	4
B		Metal U hook set	4
C		Anchors	2
D		Climbing cargo net	1
E		Extension webbing straps	4


# Step 1 : Climbing cargo net assembly on the swing set (high frame & low frame)

## Option 1: high frame

Attach extension webbing straps on metal U hook and screw the U hook on top bar of swing set (or play centre). Repeat this 4 times. Make sure to follow below instructions on swinging zone for safety purposes.

Connect the extension webbing straps with climbing cargo net by carabiner hook. Repeat this step 4 times.


- Make sure that you have a safety clearance of at least 2 m (front and back) and make sure the ground is level and shock absorbing (e.g. grass) without any sharp edges or pointed objects, obstacles, inclines, levels, steps or hard surface (e.g. concrete) etc.
- No objects of any kind must be in the vicinity of the climbing zone (trees, walls, fences, clotheslines). Obstacles, inclines, levels, steps or hard surfaces (e.g. concrete) etc.
- Clearance to stationary components on the side, must be at least 40 cm.
- Maximum raised height must not exceed 2.5m as measured from the ground.
- The hanging points must be at same width of climbing cargo net or at most as far as the net + 100mm.



## Option 2: Low frame

Attach climbing cargo net on metal U hook and screw the U hook on the top bar of the swing set (or play centre). Repeat this 4 times. Make sure to follow below instructions on swinging zone for safety purposes.

- Make sure that you have a safety clearance of at least 2m (front and back) and make sure the ground is level and shock absorbing (e.g. grass) without any sharp edges or pointed objects, obstacles, inclines, levels, steps or hard surface (e.g. concrete) etc.
- No objects of any kind must be in the vicinity of the climbing zone (trees, walls, fences, clotheslines). Obstacles, inclines, levels, steps or hard surfaces (e.g. concrete) etc.
- Clearance to stationary components on the side, must be at least 40cm.
- Maximum raised height must not exceed 2.5m as measured from the ground.
- The hanging points must be at same width of climbing cargo net or at most as far as the net + 100mm.






## Step 2 : Anchors assembly (high frame & low frame)

Assemble the anchors into ground as below figures show. Repeat this step 2 times. Make sure there are no underground utilities (electrical, gas, phone, water) before installing the anchors.

### Option 1: High frame

### Option 2: Low frame



**WARNING:** Suitable for children 6+ years. Maximum user weight 50kg. This unit is designed to be used safely by one child at a time. Only for domestic use. Outdoor use only. This must be assembled by an adult before use. Adult supervision is recommended. Falling hazard. Strangulation hazard. Anchors supplied with this product must be fitted before use.

KEYCODE: 43-113-354

MADE IN CHINA

FOR AU/NZ: IMPORTED FOR KMART  
STORES IN AUSTRALIA AND NEW ZEALAND.

KAMRT CUSTOMER SERVICE  
AU:1800 124 125 NZ:0800 945 995