

Assembly Instructions

43114641 GREY LOUNGE CHAIR


CARE INSTRUCTIONS: WIPE WITH A DRY CLOTH. DO NOT USE ABRASIVE MATERIALS AND SOLVENTS. CHECK AND TIGHTEN ALL PARTS REGULARLY. KEEP AWAY FROM WATER AND DIRECT SUNLIGHT. STORE IN A DRY PLACE. FOR INDOOR USE ONLY. FOR DOMESTIC USE ONLY.

WARNING: THIS PACKAGE CONTAINS SMALL PARTS AND SHARP POINTS. KEEP AWAY FROM CHILDREN AND BABIES UNTIL ASSEMBLY IS COMPLETE. DO NOT STAND ON THE CHAIR. USE FOR ONE PERSON ONLY. DO NOT USE THE CHAIR AS A STEP LADDER. DO NOT USE THE CHAIR UNLESS ALL BOLTS, SCREWS AND KNOBS ARE FIRMLY SECURED. DO NOT SIT ON THE ARMREST. FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.


MAXIMUM SAFE LOAD: 100KG.

Hardware list

AX1



BX4



CX16



DX1



Step 1:

