

anko

Vlogging Starter Kit **Keycode: 43126255** **Instruction Manual**



Safety Instructions:

Please read the instruction manual before using this device and follow all the safety instructions to avoid damage caused by improper use.

1. Keep the instruction manual for future reference. Should this device be given to a third party, then this instruction manual must also be handed over.
2. Keep the device away from all hot surfaces and naked flames.
3. Do not immerse the device in water or in other liquids.
4. Do not use the device in wet conditions.
5. Do not use the tripod in windy conditions or on an uneven surface.
6. Do not use the device if it is damaged.
7. This device is not a toy. Children should be supervised to ensure they do not play with the device.

Packaging include:

LED light x1

Microphone x1

Foldable Tripod Stand x1


Phone clip x1

3.5mm Aux cable for smartphone x1



Use

1. Mount phone clip on the tripod stand with the 1/4 inch mounting screw.
3. Adjust the width/length and place your smart phone in the phone holder.
4. Attach the LED light to the phone clip then tighten the cold shoe mounts.
4. Attach the microphone to the LED then tighten the cold shoe mounts.
5. Unfold the tripod legs and place it on a flat surface, both press the angle adjust button to select desired angel.
6. Put in 2 x AA batteries (not included) into the LED light back side. Long press the power button to turn on /off the light. Short press the brightness button to adjust the brightness.
7. Plug one side of 3.5mm AUX cable into the microphone, then plug another side into your phone.



Note: Smartphones without a 3.5mm jack will require an adapter such as Lightning to 3.5mm for iPhones or USB-C to 3.5mm for certain Android devices. (Adapters not included)

Specification

1. LED Light: Power:5 W;
2. LED Light working voltage: DC 3V
3. LED Light Battery:2 X AA batteries (Not included)