

anko

User Manual

LARGE POP-UP GREEN SCREEN ROUND

Keycode 43126361

Please read user manual carefully before use and keep it for your records.

Product Specifications

Open Size: 130 cm (51 inch) diameter

Folded Size: 44.5 cm (17.5 inch) diameter

How to use

Attach the product on the chair back by the straps with hook and loop, adjust to make it stable fixed.



How to fold



Fold the top and bottom of the backdrop together and centered



Rest the frame on your legs and hold the outer corners. Pull the right outer corner in toward the center



Pull the left corner in and over the right corner, pull the folded corner toward you and push the back down into alignment.



Lightly shake to even the frame before storing



Done and put it into the storage bag