Assembly Instructions

CARE INSTRUCTIONS:

WIPE CLEAN WITH A SOFT DAMP CLOTH. WHEN USE THE TOP AS A CHOPPING SURFACE, LOCK ALL WHEELS AND PLACE THE TROLLEY AGAINST WALL OR OTHER FIXED UNIT TO AVOID UNINTENDED MOVING. CHECK AND TIGHTEN ALL PARTS REGULARLY. FOR INDOOR AND DOMESTIC USE ONLY.

WARNING:

DO NOT STAND OR SIT ON THIS UNIT. DO NOT USE THIS UNIT AS A STEP LADDER. DO NOT USE UNTIL ALL BOLTS AND SCREWS ARE FIRMLY SECURED. KEEP AWAY FROM CHILDREN AND BABIES UNTIL ASSEMBLY IS COMPLETE. ADULT ASSEMBLY REQUIRED. ALWAYS SET UP THIS ITEM ON A FLAT EVEN SURFACE. ENSURE PRODUCT IS STABLE AND LOAD EVENLY. MAXIMUM SAFE LOAD WEIGHT: 20KGS FOR TOP PANEL, 5KGS FOR DRAWER, 8KGS FOR SHELF, 1.5KGS FOR HOOK, 1.5KGS FOR TOWEL RAIL.

1)									2)				
1	Α	Ø6x35mm	20PCS			L		2PCS		<u>′</u>		$\overline{}$		——————————————————————————————————————
	В		20PCS		• • • •	М	Ø 6x32mm	4SETS					4	<u>/</u>
	С	Ø6x30mm	18PCS		0	N		3PCS		1		1PC	2	
Managana	D	Ø4x40mm	11 PCS			0		1PC		'				
0	Е	Ø6x70mm	12PCS		©	 Р		2PCS						
60	F		12PCS			Q		4PCS		4		1PC	(5)	
Appendix.	G	Ø3x12mm	18PCS		Emm	R	Ø3x14mm	12PCS						<u> </u>
	Н		1PC			S		2PCS						
₹ \	···		1PC		> 000	T	Ø4x30mm	2SETS		7		1PC	8	
D	<u></u>		2PCS			U		12PCS						
	K		2PCS											≫
_			2. 30						-	10	1	PC ①		11
3)														
										14	1	PC (15		11
23		6 8		3	18		① x2							>
	2					19	20			18	2PCS	19	2PC	S











