BALANCE BIKE ASSEMBLY INSTRUCTIONS

Keycode:43144815





1.Insert the front fork, the steering limit slot is at the back



2.Assemble the clamp 1



3.Insert the handlebar with bolt cover, then tighten the clamp using wrench 2



4.Assemble the clamp 2



5.Insert the seat, then tighten it with wrench 1 to adjust the height of seat



6.Finished

WARNING: Choking hazard - contains small assembly components.

WARNING: Requires adult assembly only. Use only under adult supervision.

WARNING: Always wear an approved safety helmet, knee and elbow pads when riding.

This product is not designed for road use, not permitted for use on public roads or highways.

Please remove all packaging attachments before giving this toy to a child. Adults should check regularly to ensure the item is assembled correctly.

Warning and Notice:

- 1. This bike is only suitable for children aged 18-60 months old.
- 2. An adult must read these instructions carefully before use, otherwise it might compromise the child's safety.
- 3. Please retain this instruction sheet permanently for future reference.
- 4. This bike should not be used near fire, heat, or water.
- 5. Assembly should be done by an adult.
- 6. Adult supervision is required when using this bike.
- 7. Maximum weight limit is 20 kg.

Maintenance:

- 1. Do not expose the bike to prolonged time in the sun or rain. Store this product in a cool and dry place.
- 2. The axle should be oiled regularly.
- 3. All screw components should be checked regularly to ensure they are tightened correctly.
- 4. Use a damp cloth to wipe the bike frame.

Made in China