Assembly Instructions

43147700 Scandi Overbed Table

WARNING: IF THE OVERBED TABLE IS NOT PROPERLY ASSEMBLED AND INSTALLED, INJURY AND DAMAGE TO THE OVERBED TABLE COULD RESULT.ADJUSTABLE OVERBED TABLES HAVE A POWERFUL INTERNAL SPRING. DO NOT DISASSEMBLE THE TABLE OR LOOSEN ANY SCREWS. EXERCISE EXTREME CAUTION WHEN WORKING NEAR THE SPRING. LOAD EVENLY TO PREVENT FROM TIPPING OVER. DO REGULARLY CHECK FRAME SCREWS TO ENSURE THEY ARE TIGHT.

REGULARLY CHECK CASTORS ROLL FREELY AND LOCKS WORK.

MAXIMUM LOADING WEIGHT: 10KG. HEIGHT ADJUSTS SCOPE: 71.5-115CM.

Hardware list

A	1PC	П		2PCS	K		1PC
В	1PC	Ŋ		1PC	ال	*	1PC
С	2PCS	Н	TOP	1PC	М	5	2PCS
D	2PCS	I		1PC	N	5	1PC
E	1PC	J		1PC	0		1PC





