

Junior Sport Target Instruction Manual

8+
years

Parts List



Target (A x 1pc)



T-connector (B x 4pc)



Two way connector (C x 6pc)



Long pipe (D x 2pc)



Medium pipe (E x 6pc)



Short pipe (F x 4pc)



Hand-operated pump (G x 1pc)



Ball (H x 2pc)

Assembly Instructions

1. Open the touch fastener of the target (A), feed through 4pcs medium pipe (E) inside the target, then connect them together with T-connector (B) and two way connector (C). Fig 1.
2. Close the touch fastener, insert 2pcs long pipe (D) into the two way connector. Fig 2.



Fig 1



Fig 2

3. Connect 4pcs short pipe (F) and 2pcs medium pipe (E) together, then connect them together with 2pcs T-connector and 4pcs two way connector to form a square shape. Fig 3.
4. Insert the long pipe into the T-connector from step 3. Inflate two balls with hand-operated pump (needle is inside the pump cap). Then your sport target is successfully assembled. Fig 4.




Fig 3



Fig 4

KEYCODE: 43-148-639

MADE IN CHINA

© KMART AUSTRALIA LIMITED

FOR AU / NZ: IMPORTED FOR KMART STORES IN AUSTRALIA AND NEW ZEALAND.

KMART AUSTRALIA - 690 SPRINGVALE ROAD, MULGRAVE, VIC 3170 AUSTRALIA.

KMART NEW ZEALAND - REGIONAL OFFICE C/O KMART PAPATOETOE STORE, HUNTERS PLAZA, GREAT SOUTH ROAD, PAPATOETOE, AUCKLAND, NEW ZEALAND.

KMART CUSTOMER SERVICE

AU: 1800 124 125 NZ: 0800 945 995

WARNING:
CHOKING HAZARD
SMALL PARTS. NOT SUITABLE
FOR CHILDREN UNDER 3 YEARS.

WARNING: DO NOT AIM AT EYES OR FACE.
ADULT ASSEMBLY REQUIRED.