INSTRUCTION MANUAL

43157341

[KMT085]

KMT43157341_MAN_Waterstone Wireless Charger & Clock_V1

Artwork Proof Date: 05.19.2022

Number of artboards: 1

PAPER:

Bright white uncoated paper


PRINT COLOURS:



PRINT FINISH:

Double sided Folded in the centre

back to back print



CHANGE LOG CREST INTERNAL USE ONLY

ARTWORK SHOULD NOT BE AMENDED WITHOUT PRIOR AGREEMENT FROM CREST. ALL ARTWORK <u>MUST</u> BE APPROVED BY CREST PRIOR TO MASS PRODUCTION.

crest © The Crest Company 2022. All rights reserved.

12 month warranty

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with the accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warrantu. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or alternatively, via Customer Help at **kmart.com.au** for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave VIC 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

anko

Wireless Charger and Clock

Operating Instructions

Includes:

- > charging clock
- > user manual



43-157-341

Description:

- > Waterstone Wireless Charger & Clock
- > Easy to charge your phone without extra cables, just put your phone on the charging plate.

Specifications:

Materials: Terrazzo, Bamboo, ABS and Iron.

Input: 5V d.c. 2A / 9V d.c. 1.5A max. Wireless output: 10W/7.5W/5W Product size: 120 x 75 x 82mm Charging distance: ≤5mm Charging efficiency: ≥73%

Operation:

- > Connect the wireless charger to an outlet with an approved AC adaptor.
- > To ensure efficient charging, a 2A or higher output wall charger is requried.
- > To achieve fast wireless charging, a Quick Charge 2.0 or PowerDelivery power adapter will be required.

- > Place your phone on the charging plate and the battery will start to charge or try to remove the phone case.
- > If the phone doesn't start to charge, please try to reposition
- > Powered by 1 x AA battery (not included)

Power adaptor sold separately Clock powered by 1 x AA battery (not included) Clock without second hand

WARNING do not dispose of unit in fire or water. > Never attempt to disassemble and reassemble. > Waste electrical products should not be disposed of with household waste, please recycle where facilities exist. > Check with your local authority for recycle advice. > Keep your device and all accessories out of reach of children and animals. > Small parts may cause choking or serious injury if swallowed. > Avoid exposing your device to very cold or very hot temperatures (below 0°C or above 45°C). > Extreme temperatures can cause deforming of the device and reduce the charging capacity and life of your device. > Do not allow your device to get wet-liquids can cause serious damage. > Do not handle your device with wet hands.