

INSTRUCTION MANUAL

431161386

[KMT085]

KMT431161386_MAN_GamingMouse 16K DPI_V2


Artwork Proof Date: 04.12.2022

Number of artworks: 1

PAPER:

80gsm
Bright white uncoated paper

PRINT COLOURS:



PRINT FINISH:

Double sided
Folded in the centre

Z-fold - printed both sides



CHANGE LOG CREST INTERNAL USE ONLY


v2: replaced image on dpi setting

ARTWORK SHOULD NOT BE AMENDED WITHOUT PRIOR AGREEMENT FROM CREST.
ALL ARTWORK MUST BE APPROVED BY CREST PRIOR TO MASS PRODUCTION.
IF THERE ARE QUERIES ABOUT THIS ARTWORK PLEASE CONTACT:
EMAIL: design@crest.com.au


THANK-YOU.

Macro

- Click the "Macro".



- Click "+" as following blue rectangle marked shows to create Macro Directory, name it such as "F1", click "OK".



- You can rename/Import/Export / Encrypt Export this Macro Directory on your computer.




- Click "+" as indicated in the blue circle to create a Macro. Input Macro name such as "F2" and click "OK". Select whether to minimise the delay. Click "Recording" to start recording, define this Macro by inputting keys, then click "Stop" to finish this recording.



- Once your recording is saved, select the key button in the drop-down list.



- You can then assign created Macro in the button settings interface by pressing "Select a Macro".



Note: Ensure you click "Apply" to save all settings. Click "Reset" to reset any settings.

12 month warranty

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with the accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on **1800 124 125 (Australia)** or **0800 945 995 (New Zealand)** or alternatively, via Customer Help at kmart.com.au for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave VIC 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

anko

Pro Gaming Mouse Wired

Operating Instructions

Includes:

- gaming mouse with USB cable
- user manual



43-161-362

Default function


Support: WIN7/WIN8/WIN10/WIN11.

Connect the mouse to your PC via the USB-A Port. The mouse software will auto-install.

DPI setting

- Adjust the sensitivity: 1200-1800-2400-3600-5800-10000-19000.

Product overview



LED setting

- Press the red button ON/OFF & LED light switch to toggle between 10 light effects.



Safety Instructions

- Please read the instruction manual before using this device and follow all the safety instructions to avoid damage caused by improper use.
- Keep the instruction manual for future reference. Should this device be given to a third party, then this instruction manual must also be handed over.
- Only use this appliance indoors.
- Keep the appliance away from all hot surfaces and naked flames.
- Always put the appliance on a level, stable, clean, dry surface. Protect the appliance from extreme heat, cold, dust, direct sunlight, humidity and drops or jets of water.
- Do not immerse the appliance in water or in other liquids.
- Do not open the housing under any circumstances.
- Do not introduce any objects into the interior of the housing.
- Should the device malfunction due to electrostatic discharge or a short power surge, disconnect it from your computer and then reconnect it again.

Customized Software

- For more customized functions, please visit below to download and install the software.
- When you finished the download, click on the gaming logo below to enter the settings.

www.crest.com.au/43161362



Keys

- Choose any button such as Left Click/Right Click/Middle Button/Forward/Backward/DPI Cycle/Three Click/Light Mode Switch/Scroll Up/Scroll Down to set your mouse button functions.



- Add your profile and save.



- You can Import/Export your setting to your computer.



Performance

- DPI setting between 1000-19000.
- polling Rate/Mouse Move Speed/Mouse Scroll Speed/Double Click Speed setting.



Light

- Light Setting, select a different effect.
- Parameter Setting.

