

INSTRUCTION MANUAL

431161386

[KMT085]

KMT43161386_MAN_GamingMouse 16K DPI_V2

Artwork Proof Date: 04.12.2022


Number of artboards: 1

PAPER:

80gsm

Bright white uncoated paper

PRINT COLOURS:




PRINT FINISH:

Double sided

Folded in the centre

Z-fold - printed both sides



CHANGE LOG CREST INTERNAL USE ONLY
v2: added light mode and effects list

ARTWORK SHOULD NOT BE AMENDED WITHOUT PRIOR AGREEMENT FROM CREST.
ALL ARTWORK MUST BE APPROVED BY CREST PRIOR TO MASS PRODUCTION.
IF THERE ARE QUERIES ABOUT THIS ARTWORK PLEASE CONTACT:
EMAIL: design@crest.com.au
THANK-YOU.

DPI

- › DPI setting between 1000-16000
- › DPI Setting gear 1-6



Parameter

- › Mouse sensitivity: improve pointer precision.
- › Double Click Speed: adjust the double-click speed.
- › Rolling Speed: adjust the scroll wheel speed.



Battery Indicator



USB Polling Rate




DPI Gear logo light selection



Button Settings


Set the functions as needed for all buttons.



Macro

Add any function you need to the buttons.

- › Click "Macro".
- › Click "+New", and name it such as Anko. Click "OK", then click "Start Record" to start recording, input keys to define this Macro. Click "Stop Record" to finish the recording.
- › Select whether to increase the delay.
- › You can then assign created Macro in the button settings interface.



Note: Ensure you click "Apply" to save all settings. Click "Restore" to reset any settings.

12 month warranty

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with the accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on **1800 124 125 (Australia)** or **0800 945 995 (New Zealand)** or alternatively, via Customer Help at kmart.com.au for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave VIC 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

anko

Rechargeable Wireless RGB Gaming Mouse

Operating Instructions

Includes:

- › gaming mouse
- › USB cable
- › user manual



43-161-386

Default Functions


Support: WIN7/WIN8/WIN10/WIN11

- › Connect the 2.4G dongle to the PC till the system recognizes and installs the mouse software.
- › Connect the USB-A to the corresponding port of the PC till the system recognizes and installs the mouse software.

DPI Setting

- › Adjust the sensitivity by pressing the DPI button: 1000-1800-3800-7400-11000-16000.

Product Overview



LED Setting

- › Press ON/OFF button to switch different function.
- › Up button: Gaming LOGO light on.
- › Middle button: Gaming LOGO light on and RGB light on.
- › Down button: Turn off all the functions including the mouse function.
- › Press the RGB light effect button to choose from 10 different light effects.

Mode	Effects
1	Light off
2	Rainbow breathing
3	Violet sky
4	Breathing alternating
5	Trail wave
6	Neon breathing
7	Static star
8	Flashing neon
9	Twinkle star
10	Flashing star

Charging

- › Plug in the provided USB-C cable to the mouse, connect the other end of USB-A to PC, the red indicator light will turn on. When the mouse is fully charged, the indicator light will change to blue.

Power Saving

When the mouse is idle for more than 40s, the mouse will switch into energy saving mode. After 60s, the mouse will enter sleep mode. Click any button to wake the mouse up.

Safety Instructions.

Please read the instruction manual before using this device and follow all the safety instructions to avoid damage caused by improper use.

- › Keep the instruction manual for future reference. Should this device be given to a third party, then this instruction manual must also be handed over.
- › Only use this appliance indoors.
- › Keep the appliance away from all hot surfaces and naked flames.
- › Always put the appliance on a level, stable, clean, dry surface. Protect the appliance from extreme heat, cold, dust, direct sunlight, humidity and drops or jets of water.

- › Do not immerse the appliance in water or in other liquids.
- › Do not open the housing under any circumstances.
- › Do not introduce any objects into the interior of the housing.
- › Should the device malfunction due to electrostatic discharge or a short power surge, disconnect it from your computer and then reconnect it again.

Customised Software

- › For more customised functions, please visit below to download and install the software.
- › Tag in and you will find this main page.

www.crest.com.au/43161386




- › When you finished the download, you can find below gaming logo.



Lighting

- › Choose any lighting effect.
- › Change lighting speed.



- › Keep the profile gear 1-3.

