# **INSTRUCTION MANUAL**

# 43161409

### [KMT085]

5107\_MAN\_43161409\_GamingCurvedSoundbar\_V2

Artwork Proof Date: 02.24.2022 Number of artboards: 1

### PAPER:


Bright white uncoated paper

### **PRINT COLOURS:**



#### **PRINT FINISH:**


Double sided Folded in the centre



### CHANGE LOG CREST INTERNAL USE ONLY

ARTWORK SHOULD NOT BE AMENDED WITHOUT PRIOR AGREEMENT FROM CREST. ALL ARTWORK MUST BE APPROVED BY CREST PRIOR TO MASS PRODUCTION. IF THERE ARE QUERIES ABOUT THIS ARTWORK PLEASE CONTACT: EMAIL: design@crest.com.au

THANK-YOU.



# anko

### 12 month warranty

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with the accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or alternatively, via Customer Help at kmart.com.au for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

# **RGB Bluetooth® Gaming Curved Soundbar** Operating Instructions

Includes:

> RGB Bluetooth® Curved Soundbar


user Manual





43-161-409

**Function Overview** 



- ① Microphone jack
- 2 Volume/Mode selecting knob
- 3 Headphone jack
- 4 Audio/Headphone switch
- ⑤ RGB light
- 6 USB power interface
- 7 Green 3.5mm audio in cable
- 8 Pink 3.5mm microphone cable

### How to use this Speaker

### Power On/Off

- > Plug 6 USB cable into a USB port then press and hold 2 to turn On/Off. Speaker/Earphone Switch
- > Press 4 button to switch Soundbar speaker or Earphone

The soundbar enters AUX mode by default when powered on. Press 2 knob twice to switch to Bluetooth mode.

## **AUX Function:**

**Mode Selection** 

- The soundbar enters AUX mode by default when powered on
- > Plug in 7 green 3.5mm audio cable to connect your device. Choose music from your media device and play.

### **Bluetooth Paring:**

- > Press ② knob twice to switch to Bluetooth mode.
- > In the Bluetooth menu on the media device, search for "KM43161409" and connect. Type Password "0000" or "1234" if password requested.
- > You will hear a prompt sound once the soundbar is connected successfully.

### **RGB Light On/Off**

- > The RGB breathing light will be on when the soundbar power is on
- > Press 2 knob to switch light color: RGB breathing-RGB race-Red-Green-Blue-Light Off

### Specification:

**Model No:** 43161409

Paring Name: KM43061409

**Bluetooth Version:** 5.3

**Bluetooth Working Distance:** 10 Meters

Power Output: 2 x 5W

Frequency Response: 20Hz-20KHz

Power Supply: 5V/1A d.c