

Roller Skate

Date: 01-Apr-2022 Update:

### Manual

### ADJUSTABLE ROLLER SKATE

43164387, 43164394, 43164400 Adjustable size - PU wheels - ABEC-7 Bearings

# WARNING! PROTECTIVE EQUIPMENT SHOULD BE WORN. NOT TO BE USED IN TRAFFIC. Size 3-5 & 6-8 & 9-11 maximum loading weight 100kg.

#### CAUTION

- CAUTION:

  Read the manual carefully before using your new skates.

  Pior to acoth use, please check that all screws and connections are tightened. Make sure that the brake, wheels and bearings are in good condition.

  Self-locking nats and other self-locking fixings may lose their effectiveness after used.

  Protective equipment should be worn. We recommend you to wear a helmet, wrist, knee and elbow protectors and reflective clothing when needed.

  Use the skates with courton to avoid falls or collisions cousing injury to the user or anyone else. Do not ride your skates in slaping areas.

  Not to be used in traffic. Always follow and obey all local traffic laws and regulations. Stay away from motor verticles and watch out for pediestrians.

- vehicles and watch out for pedestrians.

  Rever allaw pourself to be pulled along by a motorized vehicle.

  Ride your skates in daylight.

  Avaid skoting in sand, water or dirt.

  Never leave your skates in extreme high/low temperatures as it might damage the skates.

  Never let children use the skates without adult supervision.

- Store the product indoors.
   Store the product indoors.
   DO NOT make any modifications to this product.
   Keep the instruction for future reference+skate maintenance.
- Note to remove any sharp edges created through use.

### MAINTENANCE

- Pilor to each use it is important to check that all screws are tightened. Check that the wheels roll properly and that the bearings are in good condition.

  Please rotate the bearings and wheels to see whether they are workable, and do some adjustments or add lubricant if its needed after the first 2 weeks of use.
- labricant if its needed ofter the first 2 weeks of use.

  The wheels and wheel bearings may become worn out ofter regular use and can be changed easily, A special key, available in most tool shops, can be used to remove the ball bearing. Clean the ball bearings using a clean, dry cloth, Lubricate the bearings if necessary.

  On a regular bases we recommend to swap the wheels around, to keep all wheels in good condition and to prevent irregular vieor.
- Try to ontsicione broking and the higher speed, the greater broking distance. Check the brake pod regularly and replace if necessary. To use the broke, bend your knees desply and put your kines have been always in a staggered position with the broke skate in front. Carefully lift the tip of the foot with the broke skate and put some weight on the heef to stop.
- This roller skate meets EN13899 Class A standards. Suitable for users up to 100kg.



### SHOE SIZE ADJUSTMENT





# Turn the fastener dockwhite to reduce the size of shoes. Turn the fastener counterclockwhis to increase the size of shoes.

# BRAKING

To apply the brake, lean backward from the waist, lift your braking skate up tilting

# STARTING OUT

# MADE IN CHINA FOR AU / N.Z. IMPORTED FOR KMART STORES IN AUSTRALIA AND NEW ZEALAND.

# RULES OF THE ROAD

Allways learn gater protective gater helmet, white guards, three and ebose pools. Learn skoring treater as the history and burning before going dut on in open hast. Stay away from water, of, obbits, sond and uneven or pooling powement. Ando arose with traffic. Never history greened along motorized vehicles. Stay alert Always be coulded or controlling the speed of your skotes. Stay in control.