Size:220*165mm folded:110*165mm

front side

Cleaning & Maintenance:

- 1) Turn the appliance off before you start cleaning it.
- 2) Do not immerse the appliance in water. Clean the appliance surface with a dry cloth or with a cloth moistened with water.
- 3) Do not use any lubricant, detergent, polishing agents ,alcohol, steel wool,abrasive cleansers,chemicals or corrosive liquids on this appliance.

Battery and appliance disposal:


1. Eco-Friendly Tips

This appliance has a lithium battery. Batteries contain substances harmful to our environment, please do not dispose of the appliance containing batteries with the normal household waste, instead, hand it over to an official recycling point.

2. Trouble Shooting

Problem	Possible Cause	Solution
LED Light is not bright enough or it does not turn on	The battery is running low or is out of power	Charge the appliance as guided





back side

Safety Instructions:

To ensure proper operation of this appliance, please read this instruction manual carefully before you use the appliance and save it for further reference.

⚠ WARNING

- Check the appliance before you use it, do not use the appliance if it has any crack, gap or any other damage.
- Make sure the mirror is not in a place or in a position where it can reflect sunlight. Reflected sunlight can cause fire.
- can reflect sunlight. Reflected sunlight can cause fire.
 Do not attempt to repair, disassemble, or modify the appliance by yourself to avoid accidents.
- The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire shall be replaced.
- For indoor use only

⚠ CAUTION


- Avoid touching the mirror with sharp objects in order to prevent scratches that might affect the mirror usage.
- This appliance has a lithium battery. Do not place or store the appliance for long periods of time in a hot or humid environment. If you do not intend to use the appliance for a long time, store the appliance after is fully charged.
- This appliance contains battery and LED lights that are non-replaceable.
- Ensure charging adapter used is compatible with a 5V / 0.5A rating.

Specifications:

- Charging Voltage/Current: 5V === /500mA
- Type of Battery: Li-polymer 3.7V 1000mAH
- Ta: 25 ℃

Product Description (picture 1):

- ① Normal mirror
- ② Touch switch
- ③ LED light
- 4 Pole
- ⑤ Base
- 6 Charging port
- ⑦ Charging indicator
- ® USB cable



Using the Appliance:

- Charging the appliance takes about 4 hours, and it can be used continuously for up to 4-5 hours for the lightest model. The charging indicator will be red while the mirror is charging and will change to green, when fully charged. To use the LED light, touch the "touch switch". There are three modes, light can change by touching the switch again.
- 1) Plug the small end of the USB cable into the port located in the backside of the mirror to charge
- 2) Press the touch switch: 35% brightness -65% brightness 100% brightness -off
- 5) With adjustable viewing angle
- 6) Charge only with supplied USB cable