

INSTRUCTION MANUAL

43133512/ 43133543/ 43133574/
43170647/ 43173654

43133512/ 43133543/ 43133574/ 43170647/
43170654 - Portable Charger - IM -V

Artwork Proof Date: 02.16.2022

PAPER:


80gsm
Bright white uncoated paper

PRINT COLOURS:

BLACK	GREY
C:0 M:0 Y:0 K:100	C:0 M:0 Y:0 K:70

PRINT FINISH:

Double sided
Folded in the centre



WARNING!

- Do not drop, misuse or put excessive force on your power bank. Power banks contain batteries and a circuit board with fragile components that can be damaged if misused. If you drop or damage your power bank, discontinue use immediately.
- If crushed, punctured, exposed to fire or high temperatures or disassembled, batteries may catch fire, explode or cause burns.
- If your power bank swells stop using it immediately and dispose of the power bank in an appropriate manner. Continued use may cause the power bank to catch fire or explode.
- Store power bank in a cool and dry place. Do not store power bank in a hot or humid environment e.g. In a car or directly in the sun.

12 month warranty
Thank you for your purchase from Kmart.
Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with the accompanying recommendations or instructions where provided.
This warranty is in addition to your rights under the Australian Consumer Law. Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect. Please retain your receipt as proof of purchase and contact our Customer Service Centre on **1800 124 125 (Australia)** or **0800 945 995 (New Zealand)** or alternatively, via Customer Help at kmart.com.au for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170. Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.
For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

WARNING Do not dispose of unit in fire or water. Never attempt to disassemble and reassemble. Waste electrical products should not be disposed of with household waste, please recycle where facilities exist. Check with your local authority for recycle advice. Keep your device and all accessories out of reach of children and animals. Small parts may cause choking or serious injury if swallowed. Avoid exposing your device to very cold or very hot temperatures (below 0°C or above 45°C). Extreme temperatures can cause deforming of the device and reduce the charging capacity and life of your device. Do not allow your device to get wet, liquids can cause serious damage. Do not handle your device with wet hands.


85 mm

130 mm

anko


Portable Charger

User Manual




43133512/ 43133543/ 43133574/ 43170647/ 43170654


Quick start guide




Accessory list:
Micro USB Cable x 1



Use the USB-A port to charge your mobile.



Charge the battery pack itself by a USB power adapter.



Charge the battery pack itself by a PC's USB port.

Specification

- Capacity: 3.6V 3300mAh battery capacity, 11.88Wh
- Battery Type: Lithium ion battery
- Input Port: Micro-USB
- Rated Input: Micro-USB 5V 2A
- Output Port: USB-A
- Rated Output: USB-A 5V 2A (Max)

Indication Light

	Capacity	LED1	LED2	LED3	LED4
Charging (White)	0~25%	Trickle	-	-	-
	25%~50%	Lights on	Trickle	-	-
	50%~75%	Lights on	Lights on	Trickle	-
	75%~100%	Lights on	Lights on	Lights on	Trickle
Discharging (White)	Full charge	Lights on	Lights on	Lights on	Lights on
	0%	-	-	-	-
	0~3%	Trickle	-	-	-
	3%~25%	Lights on	-	-	-
	25%~50%	Lights on	Lights on	-	-
Others	50%~75%	Lights on	Lights on	Lights on	-
	75%~100%	Lights on	Lights on	Lights on	Lights on
Others	When connect into power, 4 LED indication lights will trickle one by one and then stop lights on LED1/LED2/LED3/LED4.				

Important Safety Information

- Before using the unit please read this manual carefully.
- Ensure children and infants do not play with plastic bags or any packaging materials.
- Children must not use this product without adult supervision.
- Keep away from water, liquids, or wet areas.
- Use a dry cloth to clean this product. Do not use chemicals on this product.
- Do not expose the product to fire or high temperatures over 45°C.
- Make sure the product has plenty of ventilation during charging.
- Do not place the product in direct sunlight, heat or the under the windshield.
- Do not drop, stand on, puncture, or apply excessive force to the product, as harsh impacts could damage the product. If unit is dropped or otherwise damaged, discontinue use immediately.
- If crushed, punctured, disassembled, exposed to fire or high temperatures, batteries may catch fire or explode.
- If the product swells or bulges, discontinue use immediately and dispose of the unit appropriately.
- Do not insert foreign object into the product.
- Do not try to repair or disassemble this product.
- Do not charge the portable charger and charge your device simultaneously.
- This product should be only operated from the type of power source indicated on the marking label.
- To preserve battery lifespan, use and recharge at least once every 3 months.
- For long-term storage (over 3 months), charge the device between 50 percent to 75 percent charge level.
- When the unit is not in use, make sure it is correctly turned off and stored in a cool dry place.
- When disposing of this product. Do so responsibly following local government requirements.
- WARNING:**
READ AND FOLLOW ALL ABOVE INSTRUCTIONS CAREFULLY. DO NOT DROP OR APPLY EXCESSIVE FORCE TO THIS PRODUCT. DO NOT EXPOSE TO HIGH TEMPERATURES. IMPROPER USE OR HANDLING OF THIS PRODUCT MAY RESULT IN FIRE OR EXPLOSION CAUSING SERIOUS INJURY OR PROPERTY DAMAGE.