

14.2cm

anko

LED NEON LIGHT XOXO

Keycode: 43183302

Instruction manual



Instructions:

- Please read this product manual carefully.
- Read all warnings and follow all instructions in this product manual.
- Use only a microfiber and dry cloth for cleaning the product.
- Operate carefully to not cause any damage by dropping or physical shocking it.
- Do not leave the product in excessive heat, high temperatures can cause the product to malfunction.
- The light source of this luminaire is not replaceable.
- When the light source reaches its end of life, the whole luminaire shall be replaced.
- For indoor use only.

Connecting the light:

1. Plug the USB cable into a free USB port or USB wall charger with 5V 1A output.
2. The light will directly on then.
3. You can put the light on the desk or wall.

20.7cm