

size: 21*28.5CM,双面印刷,白底黑字

anko

TWISTER LAMP

Keycode: 43190393

Instruction manual



Instructions:

- Please read this product manual carefully.
- Do not touch the power supply or power cord with wet hands.
- Only use the included USB cable with the lamp.
- Use only a microfiber and dry cloth for cleaning the product.
- Operate carefully to not cause any damage by dropping or physical shocking it.
- Do not leave the product in excessive heat, high temperatures can cause the product to malfunction.
- The light source of this luminaire is not replaceable.
- When the light source reaches its end of life,the whole luminaire shall be replaced.
- If the external flexible cable or cord of this luminaire is damaged, it shall be replaced by a special cord or cord exclusively available from the manufacturer or his service agent.
- For indoor use only.

Packing list:

Twister lamp

USB cable

INPUT: DC 5V 1A

How to use:

1. Insert the USB cable (Included) into the DC hole.
2. Insert the plug into USB power supply.

