

Assembly Instructions

43221936-3 TIER TROLLEY WOOD/WIRE

WARNING: Do not stand or lean on the trolley. Use only on a flat surface. Do not use until all screws, bolts and knobs are firmly secured. This product contains small parts, keep away from children and babies. Adult assembly required.







Failure to follow these warnings could result in serious injury.









CARE INSTRUCTIONS: Wipe clean with a soft dry or damp cloth. Do not use abrasive materials solvents. Check and tighten all parts regularly. Keep away from water and direct sunlight.

For indoor and domestic use.


MAXIMUM LOADING WEIGHT: 3kg for small basket, 4kg for medium basket, 5kg for large basket.

Hardware list


	a		8PCS		d		2PCS
	b		12PCS		e		2PCS
	c		6PCS		f		1PC

							
A	2 PCS	B	2 PCS	C	4 PCS	D	1 PC
							
E	1 PC	F	1 PC	G	1 PC	H	1 PC


STEP 1



STEP 2



STEP 3



STEP 4

