

Instruction manual



Keycode: 43243952

Gaming Mouse


Please read all the information carefully before you use the product and keep the manual for future reference.

Safety Instructions:

Please read the instruction manual before using this device and follow all the safety instructions to avoid damage caused by improper use.

- Keep the instruction manual for future reference. Should this device be given to a third party, then this instruction manual must also be handed over.
- Use this device solely for its intended purpose.
- Only use this appliance indoors
- Keep the appliance away from all hot surfaces and naked flames.
- Always put the appliance on a level, stable, clean, dry surface. Protect the appliance from extreme heat and cold, dust, direct sunlight, humidity and drops or jets of water.
- Do not immerse the appliance in water or in other liquids.
- Do not open the housing under any circumstances.
- Do not introduce any objects into the interior of the housing.
- Should the device malfunction due to electrostatic discharge or a short power surge, disconnect it from your computer and then reconnect it again.

Product Overview:



Connecting the Mouse:

- 1. Plug the USB cable into a free USB port on the computer.
- 2. The mouse will connect automatically and can be used immediately.

Features:

*Selectable DPI: 1200-2400-3200-4800-6400-10000DPI. Default lamplight DPI take as yellow-blue-purple-green-red-cyan.

***13 kinds of RGB light effect**. The RGB light mode can be adjusted by long pressing the "Forward/Back button + DPI button".

1.DPI Breathing mode; 2.Cycle Breathing mode; 3.Light On mode; 4.Flowing Water mode; 5.Mono Water mode; 6.Comet Streak mode; 7.Neon mode; 8.Ambilight mode; 9.Flicker mode; 10.Star Trek mode; 11.Ripple mode; 12.Enraptured mode; 13.Button Response mode

Note: Long press the DPI button to close the light effect if no need. (More information please see the following light effects description set on software)

*supports Windows 7/8/10 or later


*For more functions, please enter "<u>http://www.intraindustry.com/downloads.html</u>" to download the driver.



Main interface and functions description:

After install **"KM43243952 Gaming Mouse Setup"**, double click it to enter the program. The main features include:

1)Button 2)Performance 3)Marco 4)Backlight



Button Function

You could switch to below 11 key functions by setting the one of these base keys: Left Click/Middle Click/Right Click/Forward/Backward/DPI Loop/Rapid Fire. Note:

a.Left Click function is necessary. If you want to set default Left Click to other function, please set other button function as Left Click first.

b.Please click the Apply button after you choose the function you want.

- 1. Left Click: Left button function
- 2. Middle Button: middle button function
- 3. Right Click: Right button function
- 4. Forward: Enter to next page
- 5. Backward: Back to previous page
- 6. DPI Loop: DPI loop switch
- 7. Rapid Fire: Long press is equivalent to constantly triggering the left button
- 8. Extend Function: Show Desktop, Double Click, Rapid Fire, LED Loop, DPI+, DPI-


2	Middle Click		MECH.	2	Middle Click	1	6
	Left Click	12			Left Click	Ĩ	2
	Middle Click			<u>_</u>	Middle Click	1	Browser
.	Right Click		5	3	Right Click		Media Player
999	Backward			<u>888</u>	Backward		Mail
a la	Forward		Show Desktop	4	Forward		Volume Up
	DPI Loop		Double Click		DPI Loop		Volume Down
	Extend	»	Rapid Fire		Extend	»	Previous Track
	Media	»	LED Loop		Media	»	Next Track
	Macro	»	DPI +	3522	Macro	»	Mute
	Shortcut	»	DPI -		Shortcut	»	Play/Pause
F	Profiles Selection	»			Profiles Selection	»	Calculator

9. Media Function: Browser, Media Player, Mail, Volume Up, Volume Down, Precious Track, Next Track, Mute, Play/Pause, Calculator

10. Shortcut Function: Copy, Paste, My computer, Undo, Lock PC, Close Window, Select All, Search

2	Middle Click		0 MECHO	2 Middle Click	MECH
	Left Click	-8		Left Click	
				Middle Click	
	Middle Click			Right Click	S (5) 👝 📑
	Right Click		5	Backward	
	Backward		Сору	Forward	
4	Forward		Paste	DPI Loop	
	DPI Loop		My Computer	Extend	» 🔪 💆
	Extend	»	Undo	Media	»
	Media	»	Lock PC	Macro	»
				Shortcut	» Office
994 <u>–</u>	Macro	»	Close Window	Profiles Selection	» Game I
	Shortcut	»	Select All		Game II
	Profiles Selection	»	Search		Media

11. Profiles Selection: Office, Game1, Game2, Media



Performance



1) Mouse Sensitivity: To adjust the movement speed of mouse

- 2) Mouse Scroll Speed: To adjust the scroll wheel speed of mouse
- 3) Double Click Speed: To adjust the double-click speed of mouse
- 4) Polling Rate: with 125Hz/250Hz/500Hz/1000Hz to choose
- 5) DPI Settings
- a. Six groups DPI: gear 1/ gear 2/ stalls 3/ stalls 4/ stalls 5/ stalls 6, check the selections
- b. DPI setting: set the 6 groups of DPI value, adjust within the range of 200 ~ 12800DPI

Macro Editor

Macro management can record any keys of keyboard, the time of keys reaction and the number of keys cycles.

a. Right-click in the Macro list box and select the New macro group Joption to create a new macro group


b. Right click on the new macro group and select 【Add a new macro】 to add a macro under this macro group

c. Click **[**record **]** and start recording any keys of keyboard. The keys you recorded will display in the macro edit box

d. After the recording, click 【Stop】 to stop recording.

e. After recording is completed, just exit the macro recording interface, no need to click the confirmation keys.

f. Execute a macro, such as the mouse button right key set to "macro functions", after recording is complete, press the mouse right key to play the recorded content.



Lighting Settings

14 kinds of light effect: DPI Breathing mode--- Cycle Breathing mode--- Light On mode--- Flowing Water mode--- Mono Water mode--- Comet Streak mode--- Neon mode--- Ambilight mode---Flicker mode---Star Trek mode----Ripple mode----Enraptured mode----Button Response mode----LED OFF

Choose one of 14 light effect you want, then click **Apply button** in Last line , the mouse will switch to the light effect you want.



Uninstall

Open the control panel and open the "Add or Remove Programs" window , find "KM43243952 Gaming Mouse" and click "delete" to complete the uninstall program.