


anko

Pet Water Fountain Mat



Contents:



Instructions:

Step 1 Connect the hose to the fountain by inserting the hose into the connector. Ensure that the hose is connected properly to stop the hose from popping out.



Step 2 Turn on the hose to make the water come out.



WARNING!

CHILDREN HAVE DROWNED IN PORTABLE SWIMMING POOLS. ENSURE ACTIVE ADULT SUPERVISION AT ALL TIMES. DO NOT LEAVE CHILDREN UNSUPERVISED IN OR AROUND THE POOL - KEEP THEM WITHIN ARMS' REACH. EMPTY AND STORE SAFELY AFTER USE.

WARNING: PET TOY - NOT INTENDED FOR CHILDREN.

IT IS THE RESPONSIBILITY OF THE PET OWNER IF THIS TOY IS SUITABLE FOR THEIR PET'S STYLE OF PLAY. NO PET TOY IS INDESTRUCTIBLE AND CAN BE DAMAGED DURING PLAY. FOR YOUR PET'S SAFETY, INSPECT REGULARLY AND REMOVE IF DAMAGED. ALWAYS SUPERVISE YOUR PET DURING PLAY.

CAUTION: ALWAYS SET UP THE POOL ON A SMOOTH, LEVEL SURFACE. AVOID SHARP OBJECTS. SUPERVISE YOUR DOG WHILE IN USE. FOR YOUR DOG'S HEALTH, REGULARLY CHANGE THE WATER AND KEEP THE POOL CLEAN.