

# Assembly Instructions

## 43277520 HAMPER WITH HANGING RAILS

### CARE INSTRUCTIONS:














WIPE CLEAN WITH A SOFT DAMP CLOTH. DO NOT USE ABRASIVE MATERIAL AND SOLVENTS. KEEP AWAY FROM WATER AND DIRECT SUNLIGHT. CHECK AND TIGHTEN ALL PARTS REGULARLY. ENSURE PARTS ARE PUSHED TOGETHER SECURELY. FOR INDOOR USE ONLY.


### WARNING:

DO NOT STAND ON THE UNIT. USE ONLY ON A FLAT SURFACE. DO NOT USE UNTIL ALL SCREWS, BOLTS AND KNOBS ARE FIRMLY SECURED. THIS PRODUCT CONTAINS SMALL PARTS AND SHARP POINTS, KEEP AWAY FROM CHILDREN AND BABIES. ADULT ASSEMBLY REQUIRED. FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.


**MAXIMUM SAFE LOAD: 5KG FOR CLOTHES RAIL, 3KG FOR HAMPER.**

### Components list


					
A	Φ 18x250mm	2PCS	B	Φ 18x720mm	2PCS
					
D	Φ 25x495mm	2PCS	E	Φ 25x620mm	2PCS
					
G	Φ 25x720mm	6PCS	H		2PCS
					
J		4PCS	K		4PCS
					
M		2PCS	N		2PCS
					
					




STEP 1




STEP 2




STEP 3



STEP 4



STEP 5



STEP 6

