

anko

ON AIR NEON SIGN
keycode: 43277636

Instruction manual



Instructions:

- Please read this product manual carefully.
- Read all warnings and follow all instructions in this product manual.
- Use only a microfiber and dry cloth for cleaning the product,
- Operate carefully to not cause any damage by dropping or physical shocking it
- Do not leave the product in excessive heat, high temperatures can cause the product to malfunction.
- The light source of this luminaire is not replaceable.
- For indoor use only

Connecting the light:

1. Plug the USB cable into a free USB port or USB wall charger with 5V 1A output.
2. Switch to turn on/off the light.
3. There are 2 handling holes, you can put the light on the desk or wall. (Installation pack is not included)